

Disney

User's Manual



ROYAL LEARNING PIANO



18+
Months

vtech®

© Disney
Visit DisneyJunior.com

© 2014 VTech
Printed in China
91-002925-000 (UK)

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtechuk.com

INTRODUCTION

Thank you for purchasing the **VTech® Royal Learning Piano!** Through four engaging modes of play your child will love learning instruments, objects, animals and more. Turn the pages and press the buttons to hear cute stories, fun phrases, music and sounds. Move the mouse to hear short tunes and princess manners. With flashing lights and Princess Sofia's real voice you can play and learn the royal way!

4 MODE BUTTONS

6 PAGE STORY BOOK

5 LIGHT UP MUSIC
NOTE BUTTONS


4 DIRECTION
MOUSE

1 DRUM BUTTON

8 PIANO KEYS

ON/OFF SWITCH

VOLUME
CONTROL SWITCH




INCLUDED IN THIS PACKAGE

- One VTech® Royal Learning Piano
- One User's Manual

WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep the user's manual as it contains important information.

Unlock the packaging locks:




① Rotate the packaging locks 90 degrees anti-clockwise.

② Pull out the packaging locks.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or screwdriver to loosen the screw.
3. Install 3 new "AA" (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

PRODUCT FEATURES

1. ON/OFF SWITCH

Slide the **ON/OFF SWITCH** from the OFF (●) position to the ON (⏻) position to turn the unit on. Slide the **ON/OFF SWITCH** from the ON (⏻) position to the OFF (●) position to turn the unit off.



2. MODE BUTTONS

Press the **MODE BUTTONS** to choose one of the four modes of play.



3. 6 PAGE STORY BOOK

Turn the pages to change the theme and story in each mode.



4. 5 LIGHT-UP MUSIC NOTE BUTTONS

Press the **LIGHT-UP MUSIC NOTE BUTTONS** to hear stories, learn instruments, objects and animals, hear music and sounds or to answer questions.



5. 8 PIANO KEYS

Press the **PIANO KEYS** to play the piano.



6. DRUM BUTTON

Press the **DRUM BUTTON** to hear a story, a new question or fun drum sounds.



7. 4 DIRECTION MOUSE

Move the **4 DIRECTION MOUSE** to hear short tunes followed by princess manners.



8. VOLUME CONTROL SWITCH

Slide the **VOLUME CONTROL SWITCH** to select from low, medium or high volume.



9. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Royal Learning Piano** will automatically turn off after several minutes without input. The unit can be turned on again by pressing any button or piano key.

ACTIVITIES

MODE 1: STORY TIME



Press the **DRUM BUTTON** to hear a story or press the **LIGHT-UP MUSIC NOTE BUTTONS** to play the story one sentence at a time. Turn the page for another different story.

MODE 2: MUSIC FUN



Press the **LIGHT-UP MUSIC NOTE BUTTONS** to hear instrument sounds and melodies. When you turn to pages 5 and 6, press the **LIGHT-UP MUSIC NOTE BUTTONS** while a melody is playing to add animal sounds to the music. Press the **DRUM BUTTON** to hear fun drum sounds.

MODE 3: QUESTION TIME



When you enter this mode you will be asked a question related to the page shown. Press the **LIGHT-UP MUSIC NOTE BUTTONS** to answer the questions. Press the **DRUM BUTTON** to hear a new question.

MODE 4: LIFE AT THE CASTLE



Press the **LIGHT-UP MUSIC NOTE BUTTONS** to learn instruments and their sounds, objects and animals. Press the **DRUM BUTTON** to hear fun drum sounds.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) with any problems and/or suggestions that you might have. A service representative will be happy to help you.



**CLASS 1
LED PRODUCT**



PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

