

**vtech**<sup>®</sup>  
Baby

Instruction Manual

# Calming Purrs Kitten



# INTRODUCTION

Thank you for purchasing the **Calming Purrs Kitten!**

Dreams can come true thanks to this kitten! This snuggly feline is ready to help babies self-soothe as they relax. With rhythmic breathing and peaceful sounds and melodies, it helps little ones enjoy quiet time with their kitty companion.



# INCLUDED IN THIS PACKAGE

- Calming Purrs Kitten
- Quick Start Guide

## **WARNING:**

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

**NOTE:** Please save this Instruction Manual as it contains important information.


## **WARNING:**

Keep this soft toy out of the sleeping environment of babies under twelve months to avoid suffocation risk.

# GETTING STARTED

## BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 4 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



## **WARNING:**

Adult assembly required for battery installation.  
Keep batteries out of reach of children.

## **IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

## **RECHARGEABLE BATTERIES:**

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## **ACTIVATE NORMAL PLAY MODE**

This product is in Try-Me mode in the package. To activate normal play mode, please turn the toy Off and then back On.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.



Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point\* so all of its materials can be recycled.

Learn more at:


[www.vtech.co.uk/recycle](http://www.vtech.co.uk/recycle)

[www.vtech.com.au/sustainability](http://www.vtech.com.au/sustainability)



\* Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.

# REMOVING THE BODY COVER OF KITTEN TO WASH

1. Remove the body cover by pulling open the hook and loop fastener, followed by disconnecting and pulling out the internal electronic module (see image).



2. To reattach, align the plush exterior tabs to the moon circle located on the chest of the kitten and press together (see image). Then, seal up the hook and loop fastener.



# PRODUCT FEATURES

## 1. On/Off/Mode Switch

To turn **On** the unit, slide the **On/Off/Mode Switch** located on the electronic module to **Melodies with Cat Purr** 🎵, **Nature Sounds** 🌿 or **Melodies** 🎵.

To turn the unit **Off**, slide the **On/Off/Mode Switch** to the **Off** ⏻ position.



## 2. Volume Switch

Press the + or - button to the desired volume level.



## 3. Light On/Off Button

Press the  button to turn the LED light **On** or **Off**.



## 4. Motion On/Off Button

Press the  button to turn the Breathing Motion **On** or **Off**.



## 5. Star Button

To activate soothing sounds or melodies press the **Star Button** once to activate for 15 minutes, twice for 30 minutes, and three times for 45 minutes. When the selected time duration has passed, the toy will automatically enter sleep mode.



## 6. Moon Button

When the product is in sleep mode, press the **Moon Button** to turn on the soft light and start playing soothing melodies and sounds. Press the **Moon Button** again to stop the current audio. To play the next melody or sound, press the **Moon Button** once again.



## 7. Automatic Shut-Off

To preserve battery life, the **Calming Purrs Kitten** will automatically power down after the selected time duration. The unit can be turned on again by pressing any button or sliding the **On/Off/Mode Switch**.

## ACTIVITIES

1. Slide the **On/Off/Mode Switch** to turn the unit **On**.



2. Slide the **On/Off/Mode Switch** to **Melody with Cat Purr** 🎵 to hear 15 random melodies with cat purring sound effects. Press the **Moon Button** (on the kitten's chest) twice to change the melody. Press the **Moon Button** to stop the current melody, then press it again to begin the next one. The LED light will fade in and out slowly with the cat purr sound effects and melodies.



3. Slide the **On/Off/Mode Switch** to **Nature Sound** 🌿 to hear 10 different types of Nature Sounds. Press the **Moon Button** (on the kitten's chest) twice to change the nature sound. Press the **Moon Button** to stop the current nature sound, then press it again to begin the next nature sound. The LED light will fade in and out slowly with the nature sounds.



4. Slide the **On/Off/Mode Switch** to **Melody** 🎵 to hear 15 different melodies. Press the **Moon Button** (on the kitten's chest) twice to change the melody. Press the **Moon Button** to stop the current melody, then press it again to begin the next one. The LED light will fade in and out slowly with the melodies.



## **Melody List**

1. Sweet Dreams Baby
2. Brahms - Lullaby
3. Tchaikovsky - Swan Lake Waltz
4. Allen - Chop Waltz
5. Rhyming River
6. Aiken Drum
7. Twinkle Twinkle Little Star
8. Beethoven - Für Elise
9. Shimmering Moon
10. Bingo
11. Mozart - Rondo alla Turca from Sonata No. 11
12. One Man Went to Mow a Meadow
13. My Little Star
14. Mary Had a Little Lamb
15. Tchaikovsky - Sleeping Beauty

## **White Noise / Nature Sound List:**

1. Stream
2. Forest Sounds
3. Wind
4. Raining
5. Bird singing
6. Campfire
7. Frogs
8. Crickets
9. Owl
10. Cicadas

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. The body fur can be removed from the toy and is hand washable for cleaning.
6. Make sure the fur is dry before reattaching it to the toy.

## TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

# CONSUMER SERVICES

Creating and developing VTech products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## **UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)  
Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

## **Australian Customers:**

Phone: 1800 862 155  
Website: [support.vtech.com.au](http://support.vtech.com.au)

## **NZ Customers:**

Phone: 0800 400 785  
Website: [support.vtech.com.au](http://support.vtech.com.au)

# PRODUCT WARRANTY/ CONSUMER GUARANTEES

## **UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

## **Australian Customers:**

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –  
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***[www.vtech.co.uk](http://www.vtech.co.uk)***  
***[www.vtech.com.au](http://www.vtech.com.au)***

