



Instruction Manual



3-in-1 Big Race Truck



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION


Thank you for purchasing the **Toot-Toot Drivers® 3-in-1 Big Race Truck**. Welcome to the **Toot-Toot Drivers® 3-in-1 Big Race Truck**, where fun drives full speed ahead! Friendly animal characters bring playtime to life, with Lion the mechanic chatting away to Tiger the driver. Place a car on the Magic Station and watch it recognise each vehicle, triggering unique lights, sounds, and voice responses. Drive over five SmartPoint™ locations to unlock more reactions. Best of all, it easily transforms from car carrier to dual raceway to auto repair shop, storing up to 11 Toot-Toot Drivers® vehicles for nonstop racing adventures.



INCLUDED IN THE PACKAGE




3-in-1 Big Race Truck



One long track B



Two track supports



One car wash roller



Three vehicles



4 screws



One Quick Start Guide



One label sheet

WARNING:


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:


Please save this Instruction Manual as it contains important information.

Unlock the Packaging Locks

- ① Rotate the packaging locks 90 degrees anticlockwise.
- ② Pull out the packaging locks and discard.



- ① Turn the packaging locks anticlockwise several times.
- ② Pull out and discard the packaging locks.

**CAUTION:****Adult assembly required.**

This package contains small screws. For your child's safety, do not let your child play with the toy until it is fully assembled.

WARNING:


Adult assembly required for battery installation.

Keep batteries out of reach of children.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover located on the bottom of the **3-in-1 Big Race Truck**. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AAA (LR03) batteries following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.



Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:


www.vtech.co.uk/recycle




www.vtech.com.au/sustainability





* Visit www.recyclenow.com to see a list of collection points near you.


LABEL APPLICATION

Please stick the labels to the play set securely as indicated on the following page:










Attention: Please choose and stick the stickers numbered 5 and 6 according to the actual shape of the car.

ASSEMBLY INSTRUCTIONS

With the **Toot-Toot Drivers® 3-in-1 Big Race Truck**, safety comes first. To ensure your child's safety, adult assembly is required.



1. Press the arrow button to remove **Long Track A**, as shown below.




2. Insert one **Track Support** into the Race Truck, then insert the **Car Wash Roller** into that **Track Support**. Insert the other **Track Support** into the other side of the Race Truck, then insert the **Car Wash Roller**, as shown below. Fasten the two **Track Supports** to the Race Truck with the four **Screws**.



3. Raise the **Top Launcher** up until it locks in place. Slide **Long Track A** into the **Track Supports**, then connect it to the **Top Launcher**, as shown below.



4. Insert **Long Track B** into **Long Track A**, as shown below. An audible click will indicate the track is securely fastened.



Once you've completed the above steps, you are ready to play!

Main Configuration



TRANSFORMATION

Race Truck Mode

1. Press the **Lift Button**, then lower the **Top Launcher** manually.



2. Fold **Long Track B** up onto the top of the truck.




Once you've completed the above steps, Race Truck mode is ready to play.



Reverse these steps to return to Race Track mode.

Repair Shop Mode

1. Press the two small buttons on **Long Track B** to release it, then insert the track into the slot on the side of the Race Truck near Lion.



2. Press the arrow button to release **Long Track A**. Connect it at the back of the Race Truck.



Once you've completed the above steps, Repair Shop mode is ready to play.




Reverse these steps to return to Race Truck mode.

PRODUCT FEATURES

1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** () position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** () position.



2. Automatic Shut-Off


To preserve battery life, the **Toot-Toot Drivers® 3-in-1 Big Race Truck** will automatically enter Sleep mode after approximately **50** seconds without input. Wake the unit from Sleep mode by pressing any button, raising or lowering the top launcher, or putting any of the included cars on the Magic Station. If the unit powers down while playing, we suggest changing the batteries.

3. Try Me Mode

Note: This product is in Try-Me mode in the packaging. After opening the package, raising or lowering the top launcher or putting any included car on the Magic Station will exit Try-Me mode and proceed with normal play.

ACTIVITIES

1. Slide the **On/Off Switch** to **On**. You will hear sounds, fun phrases and a song. The lights will flash with the sounds.



2. Put a **Vehicle** on the **Magic Station** to provide repair shop responses and to recognise the vehicles, introducing animals, colours, and numbers. The lights will flash with the sounds.




3. Press the **Light Up Music Button** to hear songs and music. The lights will flash with the music. Park a vehicle and press the button to hear vehicle-related songs and upbeat melodies.



4. Press the **Number Button** to have Lion repair vehicles while simultaneously teaching numbers. The lights will flash with the sounds. Park a vehicle and press the button to hear vehicle-related responses.



5. Press the **Car Wash Button** to introduce a car wash activity with fun phrases and sounds. The lights will flash with the sounds. Park a vehicle and press the button to hear vehicle-related responses.



6. Press the **Maintenance Button** to trigger repair-related responses. The lights will flash with the sounds. Park a vehicle and press the button for responses related to each vehicle.



7. Press **Lion** to hear fun repair shop responses, fixing cars and interacting with animals. The lights will flash with the sounds. Having a vehicle on the **Magic Station** will trigger vehicle-related responses.



8. Lift the **Top Launcher** to trigger fun racing sounds. Once you're done, press the **Lift Button** to unlock the **Top Launcher** from its raised position, then lower the **Top Launcher** manually.



9. Put a Car on the **Top Launcher**, then lift it up to launch the **Car** down the ramp.



10. Park a Car on the **Magic Station** and press the **Bottom Launcher Button** to launch a **Car** down the ramp.



11. Put a **Car** at the back of the Repair Shop, and push the **Car** to launch down the ramp.



12. Place any **Toot-Toot Drivers**® vehicle (each sold separately) on any of five **SmartPoint**® locations to trigger fun sounds, songs or phrases.



SONGS

Song 1

Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 2

Number 1, bright red, let's play
Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 3

Blue 2, leading the way
Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 4

Number 3 rules the raceway
Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 5

One, two, three, four, five,
Tiger, take us on a drive!

Song 6

Number 1, bright red, let's play

Song 7

Blue 2, leading the way

Song 8

Number 3 rules the raceway

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play with again.
5. If the unit is not working properly, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au



© 2026 VTech.
All rights reserved.
IM-589100-001
Version: 1