



Instruction Manual

Big Sister Peppa Pig Learning Book



Licensed by:



HASBRO and PEPPA PIG and all related trademarks and characters TM & © 2025 Hasbro/Hasbro Consumer Products Licensing Ltd. Peppa Pig © 2003 Astley Baker Davies Ltd. and HCPL Ltd. All Rights Reserved. Used with Permission.

Peppa Pig created by Mark Baker and Neville Astley.

INTRODUCTION

Thank you for purchasing the **Big Sister Peppa Pig Learning Book!** This book shows Peppa's newly expanded family through four learning modes. Through exploring each page with Peppa Pig and her family, your child will learn letters, vocabulary and how to be the best big sister.



① Four Light-Up Buttons

② On/Off Button

③ Volume Button

④ Search & Find Mode

⑤ Daddy Pig Button

⑥ George Pig Button

⑦ Peppa Pig & Evie Pig Button

⑧ 14 Book Pages

⑨ Big Sister's Story Mode

⑩ ABC Mode

⑪ Nurturing Mode

⑫ Mummy Pig Button

INCLUDED IN THE PACKAGE

- **Big Sister Peppa Pig Learning Book**
- **Quick Start Guide**

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.


ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

Unlock the Packaging Locks:



① Rotate the packaging locks 90 degrees counterclockwise.

② Pull out and discard the packaging locks.

GETTING STARTED

Battery Removal and Installation

Before playing for the first time, please install 2 new AA batteries(The AA batteries included in the unit are for demo purposes only and are not long life batteries).



WARNING:


Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the bottom of the unit and use a screwdriver to loosen the screw, then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (LR6/AM-3) batteries, following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



IMPORANT: BATTERY INFORMATION


- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.


RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT FEATURES

1. On/Off Button

Press the **On/Off Button**  to turn the unit **On**. To turn the unit **Off**, press the **On/Off Button** again.



2. Volume Button

Press the **Volume Button**  to adjust the volume level.



3. Big Sister's Story Mode Button

Press the **Story Mode Button** to hear Peppa read the Big Sister's Story.



4. ABC Mode Button

Press the **ABC Mode Button** to learn and explore letters and vocabulary.



5. Nurturing Mode Button

Press the **Nurturing Mode Button** to learn with Peppa how to take care of her baby sister.



6. Search & Find Mode Button

Press the **Search & Find Mode Button** to play a search and find game with Peppa.



7. Character Buttons

Press the **Peppa Pig & Evie Pig, Daddy Pig, Mummy Pig and George Pig Buttons** to hear the characters.



8. Four Light-Up Buttons

Press the **Light-Up Buttons** to answer the questions, play sounds and hear Peppa read the story. The lights will flash with the sounds and music.



9. 14 Book Pages

Press the **Story Mode Button** to hear Peppa read the story to you.

10. Automatic Shut-Off

To preserve battery life, the unit will automatically power down after approximately 1 minute without input. The unit can be turned **On** again by pressing the **On/Off Button**.

NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES



1. Big Sister's Story Mode

Explore Peppa's big sister life! Open the book and press the **Light-Up Buttons** to listen to Peppa read each page of the illustrated book.



2. ABC Mode

Let's learn and explore letters and vocabulary. Open the book and press the **Light-Up Buttons** to learn about family and objects on the pages.



3. Nurturing Mode

Enjoy big sister time! Open the book and press the **Light-Up Buttons** to take care of baby Evie with Peppa.



4. Search and Find Mode

Let's help Peppa find the letters and words she's looking for on each page. Open the book and press the **Light-Up Buttons** to answer the questions.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5467
Product Name: Big Sister Peppa Pig Learning Book
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
CAN ICES(B)/NMB(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com

vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

