

vtech[®]
baby

Instruction Manual

Crawl with Me Elephant



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk


INTRODUCTION

Get baby moving with the **Crawl with Me Elephant** by VTech®! This cute, playful elephant will be baby's new best friend. Elephant encourages little ones to crawl and walk after her with bright flashing lights and flapping ears.

Number Button

Light Up Star Button

Music Button



Elephant Button

Flapping Ears



On/Off/Volume Switch

INCLUDED IN THIS PACKAGE


- One VTech® Crawl with Me Elephant
- One Quick Start Guide

WARNING: All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please save this Instruction Manual as it contains important information.

WARNING: Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.

Unlock the Packaging Locks:




① Rotate the packaging locks anticlockwise 90 degrees.

② Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the elephant's tummy and use a screwdriver to loosen the screw and open the battery cover.
3. Remove the old batteries by pulling up on one end of each battery.
4. Install 3 new AA batteries following the diagram inside the battery box.
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle


www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit **On**, slide the **On/Off/Volume Switch** to the Low volume **|)** or the High volume **))** position. You will hear a song, a phrase and a short tune. To turn the unit **Off**, slide the **On/Off/Volume Switch** to the **Off ●** position.



2. Automatic Shut-Off

To preserve battery life, the **Crawl with Me Elephant** will automatically shut off after 20 seconds without input. The unit can be turned on again by pressing any button.

NOTE

This product is in Try-Me mode in the packaging. After opening the package, turn the **Crawl with Me Elephant** off and on again to proceed with normal play. If the unit repeatedly powers down while playing, please install a new set of batteries.


NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES


1. Elephant Button

Press the **Elephant** button to hear fun sounds and phrases. The elephant will flap its ears and crawl forward.




2. Music Button

Press the **Music** button to hear playful melodies and songs. The elephant will flap its ears and crawl forward.




3. Number Button

Press the **Number** button to learn numbers, body parts and the colour of the shape. The elephant will flap its ears and move forward during the playful number song.



4. Light Up Star Button

Press the **Light Up Star** button to hear fun sounds, phrases and a playful song that encourage interaction and crawling. The elephant will flap its ears and move forward during the sing-along song. The light will flash with the sounds.



SONG LYRICS

Song 1

I like to crawl along,
It's fun to crawl with you.
I like to explore the world,
To explore and play with you.

Song 2

It's time to explore the big world, the big world.
Let's crawl and explore together, together.
Let's move along and see, what a thrill it is to me.
Let's go!

Song 3

Here we go, one leg in.
Here we go, two legs out.
Here we go, three legs in.
All four legs are ready to crawl.

MELODY LIST

1. Bingo
2. Mary Had a Little Lamb
3. Pat-a-Cake
4. Pease Porridge Hot
5. Skip to My Lou
6. This Old Man
7. Animal Fair
8. Three Little Kittens
9. To Market, to Market
10. London Bridge
11. Hickory, Dickory, Dock
12. Au Clair de la Lune
13. Alouette
14. Oh, Susanna
15. Flight of the Bumble Bee

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au



TM & © 2020 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003811-005 