

vtech®

Parent's Guide

Magical Lights Unicorn



91-003544-006 

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **Magical Lights Unicorn**.

This enchanting unicorn features three modes of play, colourful charms and a light-up horn. Place the charms on the magic heart recognition points to decorate the unicorn and hear colours and fun phrases in English and French, plus whimsical sounds. Squeeze her tail to flap her wings as she rolls along!



Seven Charms

(Blue Butterfly, Green Diamond, Yellow Star,
Red Cherries, Rainbow, Purple Heart, Orange Flower.)

INCLUDED IN THIS PACKAGE


- One **Magical Lights Unicorn**
- One charm storage dish
- Seven charms
- One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please keep this parent's guide as it contains important information.

Unlock the packaging locks:



- ① Rotate the packaging locks anticlockwise 90 degrees.
- ② Pull out the packaging locks.

Release the charm:


1. Make sure the unit is **OFF**.
2. Carefully pull the charm away from the unicorn and cut the strings as illustrated.
3. Remove the strings from the unicorn and throw them away.



GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the side of the unit.
3. Use a screwdriver to loosen the screw and open the battery cover.
4. Install 2 new AA (AM-3/LR6) batteries into the battery box as illustrated. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.


For more information, please visit:



www.recycle-more.co.uk

www.recyclenow.com

PRODUCT FEATURES

1. Off/Mode Selector

To turn the unit **ON**, slide the selector from **OFF**  to **Charms & Colours**, **Charms & Colours in French** or **Music Time**.

To turn the unit **OFF** , slide the selector to the **OFF**  position.



2. Volume Switch

The **Volume Switch** is located on the side of the unicorn. To adjust the volume, slide the **Volume Switch** to the **Low Volume** or **High Volume** position.



3. Seven Charms

Place the **Seven Charms** on the **Magic Heart Recognition Points** to hear fun responses about the charms.



4. Magic Heart Recognition Points

Place a **Charm** on any of the three **Magic Heart Recognition Points** on the unicorn to trigger fun responses and lights. She has **Magic Heart Recognition Points** on her crown, bracelet and side.



5. Magical Light-Up Horn

The **Magical Light-Up Horn** will light up in multiple colours with the voice responses, songs and melodies.



6. Magical Tail

Squeeze her **Magical Tail** to flap her beautiful wings and hear fun responses and songs.




7. Blue Heart Button

Press the **Blue Heart Button** to hear questions, fun phrases about the unicorn and to play melodies.



8. Necklace Button

Press the **Necklace Button** to hear fun sounds and see the unicorn's horn light up.



9. Rolling Wheels

The unicorn's hooves feature wheels so you can push her along.



10. Charm Storage Dish

Store the **Seven Charms** in the heart-shaped **Charm Storage Dish**.



11. Automatic Shut Off

To preserve battery life, **Magical Lights Unicorn** will automatically power down after several minutes of no input. The unicorn can be turned on again by sliding the **Off/Mode Selector** to **Charms & Colours**, **Charms & Colours in French** or **Music Time**.

NOTE: If the unicorn powers down while playing, we suggest replacing with a new set of batteries.

ACTIVITIES:

1. Charms & Colours

- Place a **Charm** on any of the three **Magic Heart Recognition Points** to hear about colours, beginning letters and fun phrases.
- Press the **Blue Heart Button** to hear questions about the charms, then place the charms on one of the **Magic Heart Recognition Points** to answer the questions.

2. Charms & Colours in French

- Place a **Charm** on any of the three **Magic Heart Recognition Points** to hear colours and phrases in French.
- Press the **Blue Heart Button** or squeeze the **Magical Tail** to hear fun responses about the unicorn in French.

3. Music Time

- a. Place a **Charm** on any of the three **Magic Heart Recognition Points** to hear fun sounds.
- b. Press the **Blue Heart Button** to play melodies, or squeeze the **Magic Tail** to play songs, then press the **Necklace Button** or place any of the **Seven Charms** on a **Magic Heart Recognition Point** to add sounds into the melodies and songs.

SONG LYRICS

Song 1:

I'm a Magical Lights Unicorn,
Won't you come and shine with me!
Let's go!

Song 2:

Let's play with all these colourful charms.
There's purple, orange and blue,
yellow, green and red too.
So won't you put in the perfect charm for me?
Is it a star or a lovely cherry?
They're so much fun for you and me!

Song 3:

Regarde ces beaux bijoux colorés,
violet, orange et bleu,
Des jaunes, des verts, des rouges.
C'est parti trouve le parfait bijou pour moi.
Est-ce une étoile ou une jolie cerise ?
Ensemble on sera les meilleures amies !

Song 4:

Flying from here to there
Got wings on my back and colours in my hair! Oh yeah!
And magic under my feet!
It's really sweet!
I'm a Magical Lights Unicorn
Won't you come and shine with me!
Let's go!

Song 5:

Fly with me my best friend,
To a magical world of colourful fun.

MELODY LIST

1. Twinkle, Twinkle Little Star
2. Sing a Song of Sixpence
3. Little Miss Muffet

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions while playing with the **Charms**, please remove the **Charms** and place them back onto the unicorn.

If the unit still isn't functioning, or if for some reason the unit stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1
LED PRODUCT



PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login
to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



PRODUCT WARRANTY

Thank you for choosing this quality product from VTech.
We hope it will bring many hours of entertainment,
imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
9. To keep an online record of your warranty, please register your product online at www.vtech.co.uk/warranty

VTech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.





**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk



TM & © 2018 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003544-006 ©

