



Quick Start Guide



My Mini Locker™



We aim to reduce our environmental impact and have reduced the amount of paper used for our printed manuals. The full version of the manual is available online through the following link or by scanning the QR code.

For USA



vtechkids.com/guides

For Canada



vtechkids.ca/en/guides


For AUS/NZ



[vtech.com.au/support/
product_manuals](http://vtech.com.au/support/product_manuals)

© 2026 VTech. All rights reserved. Printed in China.

91-004824-004 (3) (3) (3)



INTRODUCTION

Unlock a world of fun and secrets with **My Mini Locker™** by VTech®! Keep your treasures safe with your very own 4-digit passcode, reveal hidden messages with the **Secret Message Light**, and customize your locker with stickers and glowing frame lights. Set the time and use it as an alarm clock. Connect your music player via **Bluetooth®** to listen to your own music or enjoy 40 built-in melodies and cool games.

INCLUDED IN THIS PACKAGE

- My Mini Locker
- Drawer (with secret compartment!)
- Adjustable Spacer
- 1 Sticker Sheet
- Memo Pad
- Invisible Ink Pen
- 4 Pegboard Hooks

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Quick Start Guide as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de conserver ce guide de démarrage rapide car il comporte des informations importantes.



WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 yrs.



AVERTISSEMENT:

RISQUE DE SUFFOCATION—Petites
pièces. Ne convient pas aux enfants
de moins de 3 ans.

GETTING STARTED

IMPORTANT! Exiting from Try-Me mode

My Mini Locker is in Try-Me (demo) mode in packaging. To exit Try-Me mode:

1. Open the battery compartment
2. Locate the **Reset Button**
3. Using a pen tip or other small object, press and hold the **Reset Button** for about 2 seconds.


You will enter the Time Set-Up page after exiting Try-Me mode.



INITIAL SET-UP

1. TIME SET-UP

When you first use the **My Mini Locker**, or change the batteries, you will need to set the time. Press the **Left** or **Right Button** to select 12- or 24-hour time format and press the **OK Button** to confirm, then press the **Number Buttons** to input the time, then press the **OK Button** to confirm.




2. PASSCODE SET-UP

Press the **Number Buttons** to create a 4-digit passcode, then press the **OK Button** to confirm. Remember your passcode! If you lose it, you can reset it using the **Reset Button**.

Quick Operation Guide

When **My Mini Locker** is **Off**, press any button (except the Secret Message Light Button) to turn it **On** and display the time.

1. To open the locker, press the Unlock Button  and enter the passcode.
2. Press the **Home Button**  to enter the menu, then use the **Left/Right Buttons** to navigate to the correct section and press the **OK Button**  :
 - Games Menu
 - Music Menu
 - Alarm Clock and Timer Settings
 - Device Settings
3. To read secret messages written with the **Invisible Ink Pen**, press the **Secret Message Light Button**  to turn on the UV light and hold the message under the light.
4. Press the **Bluetooth Button**  to connect your music player to listen to your favorite music.
5. To change the clock face, press the **Clock Button** and use the **Left/Right Buttons** to select it.
6. The device will automatically power off after several minutes without input, or you can press the **Clock Button** twice to enter sleep mode immediately.





Bluetooth® Pairing

1. Press the **Bluetooth Button**  or select the Bluetooth Icon in Music Mode to enter Bluetooth mode. The **Bluetooth Connection Light** will flash blue on **My Mini Locker** while waiting for a connection.
2. Enter the Bluetooth interface of your device and search for Bluetooth devices.
3. On your device, select “**VTech 5944 Locker**”.
4. Enter the PIN number from the **My Mini Locker**’s display screen on the device.
5. While in Bluetooth mode, the **Bluetooth Connection Light** will remain **On**.
6. To exit Bluetooth mode, press the **Bluetooth Button** again.
7. The Locker will automatically search and connect to the last Bluetooth device that it was connected to before. You do not need to repeat this process the next time you want to use the same device.

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 4 new AA (AM-3/LR6) batteries following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.





WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :


Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.



IMPORTANT : INFORMATIONS CONCERNANT LES PILES


- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -).
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.

PILES RECHARGEABLES :

- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. If the unit stops working or malfunctions, install a new set of batteries.



IMPORTANT NOTE


If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or visit our website **vtechkids.com** and fill out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Bluetooth® Statement

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth® SIG, Inc. and any use of such marks by VTech® is under license. Other trademarks and trade names are those of their respective owners.

RF Warning Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5944
Product Name: My Mini Locker
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE,
AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE
RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE
UNDESIRE OPERATION.