

vtech[®]

Instruction Manual

Scoop & Score Dolphin



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Introducing the **Scoop & Score Dolphin** by **VTech**®! This dolphin hoop features three balls for fun basketball play and a fun sized pouring cup for pouring play. The light up star button plays fun phrases, sing-along songs and melodies to make playtime more exciting. The two suction cups on the back of the dolphin allow it to easily attach to the side of the bath or bathroom wall. Make a splash with every shot!



INCLUDED IN THE PACKAGE

- Scoop & Score Dolphin
- 3 Balls
- Pouring Cup
- Quick Start Guide


WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE


Please keep this Instruction Manual as it contains important information.

Unlock the Packaging Locks:



- ① Rotate the packaging locks 90 degrees anticlockwise.
- ② Pull out the packaging locks and discard.

- ① Turn the packaging locks anticlockwise several times.
- ② Pull out the packaging locks and discard.



WARNINGS:

- Battery must be changed by an adult.
- We do not recommend submerging the unit in the water. If the unit does get submerged in the water, please dry the unit completely before changing the battery.
- This toy can only be operated in water when fully assembled in accordance with the instructions.
- When closing the battery cover ensure that the screw is securely tightened. This will avoid any water leakage.
- To prevent drowning, never leave a child unattended in the bath.
- Use a thermometer to check the temperature of the water before sitting a child in the bath. Toddlers have very sensitive skin and can burn easily if the water is too hot.
- In case of eye contact the foam, immediately rinse the eye with clean water.
- Please check the suction cups periodically as they may detach after prolonged use.
- Children should not play with the suction cups when the unit is attached to the wall as the unit may detach and cause injuries.
- To prevent the risk of injuries, do not attach the **Scoop & Score Dolphin** any higher than a child's head height when sitting in the bath.

This electronic toy is intended for use on the side of the bath and is waterproof when used as intended. Water cannot enter the electronics if the battery compartment door is locked correctly.


The design is verified by submerging the toy underwater to a depth of 15cm for 30 minutes. There will be a reduction in acoustic performance when the toy is submerged in water.

Adult supervision needed.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If a used battery is present, remove the battery from the unit by pulling up on one end of the battery.
4. Install 1 new AAA (AM-4/LR03) battery following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle


www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.


PRODUCT ASSEMBLY

With the **VTech® Scoop & Score Dolphin**, safety comes first. To ensure your child's safety, adult assembly is required.

1. Choose a surface on the wall surrounding the bath where the suction cup support unit can be mounted securely. The area should be clean and dry before suctioning the unit to the wall. For better suction, we suggest wetting the suction cups before attaching them to the wall. Press the suction cups onto the wall to secure the suction cup support unit. Once the unit is attached to the wall, test the strength of the suction by pulling gently on the unit. The suction cups may not stick properly to textured tiles. We recommend that the unit be removed from the wall after each use as the strength of the suction cups cannot support prolonged use.
2. Pull up the hoop to a horizontal angle, once you hear a click sound, the hoop is fixed successfully.





3. To remove the unit from the wall, pull the tab on the suction cup and pull the dolphin gently.




WARNING:

To prevent the risk of injuries, do not attach the VTech® Scoop & Score Dolphin any higher than a child's head height when sitting in the bath.

PRODUCT FEATURES

1. To turn the unit **On** , press the **On/ Off Button**. You will hear a song, 2 phrases and sounds. To turn the unit **Off** , press the **On/ Off Button** again. The unit will shut down after playing a short melody.



2. Automatic Shut-Off

To preserve battery life, the **Scoop & Score Dolphin** will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing the light up button, the Hoop or the on/off button.

NOTE

If the unit powers down or if the light fades out during play, please install a new battery.

ACTIVITIES

1. Light up Button

Press the **Light up Button** to play fun phrases and hear sing-along songs, fun sounds and melodies.



2. Hoop

Press the Hoop slightly to hear fun sounds, the Hoop will rebound automatically. Throw the balls into the Hoop to have fun! The Hoop can be pulled down vertically for easier storage.



3. Pouring Play

Pour water on the dolphin's head with the pouring cup to see a magical water effect on the hoop.



MELODIES

1. There Is A Tavern In The Town
2. Blue Danube Waltz
3. Chicago
4. Diddle, Diddle Dumpling
5. I'm Forever Blowing Bubbles
6. Row, Row, Row Your Boat
7. Sailing Sailing
8. Sailor's Hornpipe
9. I Want To Go Back To Michigan, Down On The Farm
10. Little Robin Red Breast
11. Little Tommy Tucker
12. MacNamara's Band

SONG LYRICS

Song 1

I'm a happy dolphin who likes to play,
I'm a happy dolphin who likes to play.
Let's splash and have some fun!

Song 2

Think fast, you can catch it,
The ball goes in the basket,
Splashing fun, now you've won,
Time to play again!

Song 3

Wash our face and toes, face and toes,
Then our ears and nose, ears and nose,
We are sparkly clean from head to toe.

CARE & MAINTENANCE

1. Remove the unit from the wall after each use.
2. Keep the unit clean by wiping it with a slightly damp cloth.
3. Keep the unit out of direct sunlight and away from any direct heat source.
4. Make sure to dry all the elements of the unit before storing.
5. Remove the batteries when the unit will not be in use for an extended period of time.
6. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play with again.
5. If the unit is not working properly, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

