

vtech[®]
baby

Instruction Manual

Snuggly Sounds Whale



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **Snuggly Sounds Whale**.

Cuddle up with this wonderful whale featuring multiple textures, a light up heart button, five multicoloured piano keys and more! Explore and snuggle!



INCLUDED IN THE PACKAGE

- Snuggly Sounds Whale
- Quick Start Guide

WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

WARNING: Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.


IMPORTANT NOTES

This product is in try-me mode in the packaging. To activate normal play, turn the unit **Off**, then slide the **On/Off/Volume Switch** to the Low volume **⏪** or High volume **⏩** position.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the bottom of the electronic module inside the whale, use a screwdriver to loosen the screw, and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle

www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit **On**, slide the **On/Off/Volume Switch** located on the electronic module to the Low volume **||** or High volume **|||** position. You will hear a sound, phrases, and a song. To turn the unit **Off**, slide the **On/Off/Volume Switch** to the **Off ●** position.



2. Automatic Shut-Off

To preserve battery life, the **Snuggly Sounds Whale** will automatically power down after approximately 25 seconds without input. The unit can be turned on again by pressing any button.


NOTE

If the unit powers down or the light fades out during play, please install a new set of batteries.

ACTIVITIES


1. Light Up Heart Button

Press the **Light Up Heart Button** to play fun whale facts and songs. The light will flash with the sounds.




2. Piano Keys

Press the **Piano Keys** to learn about animals, numbers, counting, colours and shapes, hear fun sounds and short tunes. The light will flash with the sounds.




3. Music Button

Press the **Music Button** to hear fun sing-along songs and melodies. When a melody is playing, press the **Piano Keys** to hear the song played note by note. The light will flash with the sounds.



4. Ocean Sounds Button

Press the **Ocean Sounds Button** to hear fun underwater sounds. The light will flash with the sounds.



MELODIES

1. MacNamara's Band
2. Row, Row, Row Your Boat
3. Aiken Drum
4. Blue Danube Waltz
5. Looby Loo
6. Blow the Man Down
7. Sailor's Hornpipe
8. Skip to My Lou
9. Glow Worm
10. Colonel Bogey March
11. Chopsticks
12. Dill Pickles Rag
13. Sailing, Sailing
14. Diddle, Diddle, Dumpling
15. Humpty, Dumpty

SONG LYRICS

Song 1

Big, big whale, swimming in the sea.
Big, big whale, singing merrily.
In the ocean with all of my friends,
Splishing and splashing again and again!

Song 2

Diving, diving, down in the deep blue sea.
Swimming here, swimming there,
So many fun things to see!

Song 3

I'm a plishy, splashy whale,
Would you like to come play with me?

Song 4

I'm a big whale, living in the sea.
When I come up for air, you'll see me spout!
Water sprays out of my blowhole like a fountain.
I like to make a splash with my tail,
Then I'll take a big breath and dive down to the bottom of the sea.

Song 5

Crab's two claws go snip, snip, snap!
Snip, snap, snippity snap!

Song 6

Fishy, fishy, swimming in the sea,
Puff, puff, puffer fish, puffs up like a ball!

Song 7

Jellyfish is in the sea, wiggling and jiggling for us to see.

Song 8

Sea turtle peaceful and calm,
Quietly glides through the water.

Song 9

Playful dolphin, whistles and clicks,
Splishes and splashes and dives in the sea.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. The fabric whale is surface washable only. Do not submerge the whale in water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

CONSUMER SERVICES

Creating and developing **VTech**[®] products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

