

**vtech**<sup>®</sup>  
Baby

# User's Manual

## Spin & Learn Colours Torch



© 2016 VTech  
Printed in China

91-003166-006 UK

**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

### **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

### **vtech Baby**

**Toys that will stimulate their interest in different textures, sounds and colours**

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

4-10 years

Birth-36 months

3-6 years




To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Thank you for purchasing the **VTech® Spin & Learn Colours Torch** learning toy!

Shine a light on learning with the **Spin & Learn Colours Torch**. The cute turtle button plays happy phrases and turns on the torch. 6 different coloured lights and animals attract baby's attention. Turn the ring to change the coloured lights and discover the sounds the animals make. Press the buttons to play games, learn letters or listen to music.




# INCLUDED IN THIS PACKAGE

- One VTech® Spin & Learn Colours Torch
- One user's manual

**WARNING:** All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

**NOTE:** Please keep this user's manual as it contains important information.

**Unlock the packaging locks:**




- ① Turn the packaging lock counter-clockwise several times.
- ② Pull out and discard the packaging lock.

## GETTING STARTED

### BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 3 new AAA (AM-4/LR03) batteries following the diagram inside the battery box.
4. Replace the battery cover and tighten the screw to secure the battery cover.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

### Disposal of batteries and product

The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:


[www.recycle-more.co.uk](http://www.recycle-more.co.uk)

[www.recyclenow.com](http://www.recyclenow.com)

# PRODUCT FEATURES

## 1. ON/OFF/MODE SELECTOR SWITCH

To turn the unit **ON**, slide the **ON/OFF/MODE SELECTOR SWITCH** to the **TORCH MODE** (💡) or **PLAY MODE** (📖) position. To turn the unit **OFF**, slide the **ON/OFF/MODE SELECTOR SWITCH** to the **OFF** (●) position.




## 2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Spin & Learn Colours Torch** will automatically power-down after approximately 65 seconds without input. The unit can be turned on again by pressing any button or turning the ring.

# ACTIVITIES

1. Slide the **on/off/mode selector switch** to play mode position and hear a short tune, a phrase and a song. The lights will flash with the sound. Slide the switch to torch mode position and hear a fun sound. The light will flash with the sound.



2. Press the **turtle button** in play mode to hear playful phrases and sounds. The lights will flash with the sound. In torch mode, hold down the turtle button to turn on the torch. The torch will remain on when the turtle button is being pressed. To preserve battery life, the torch will automatically power-down after being on for 2 minutes.



3. Press the **music button** in play mode to hear melodies with nature sounds. The lights will flash with the sound. In torch mode the music button will play a sound and the turning ring will light up in the related colour.



4. Press the **letter button** in play mode to hear a song or melody. The lights will flash with the sound. In torch mode the letter button will play a sound and the turning ring will light up in the related colour.



5. Press the **question button** in play mode to hear a question, turn the turning ring to answer the question. The related light will flash. In torch mode the question button will play a sound response and the turning ring will light up in the related colour.



6. Turn the **turning ring** so one of the animals is positioned in front of the pointer. In play mode, you will hear the colour or the animal identified or hear a fun phrase related to the animal. The lights will flash with the sound. Turn the ring while a melody is playing to hear the animal sound play over the melody. In torch mode, you will hear a sound and the spinning ring will light up in the related colour.



# MELODY LIST:

1. Alphabet Song
2. Farmer in the Dell
3. Blow The Man Down
4. Camptown Races
5. Are You Sleeping?
6. The Entertainer
7. Goosey Goosey Gander
8. Hickory Dickory Dock
9. Froggy Went a Courtin'
10. Down By the Riverside
11. Glow Worm
12. Oh! Susanna
13. Polly Wolly Doodle
14. Old MacDonald Had a Farm
15. Lazy Mary Will You Get Up?

# SING-ALONG SONG LYRICS

## SONG 1

I like to explore, there's lots for me to see.  
Turn on my light and we'll go on an adventure.

## SONG 2

A, B, C, D, E, F, G.  
Come along, explore with me.

# CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING


If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

## IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.





## PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).  
Please include details of the fault together with your name and address.
9. To keep an online record of your warranty, please register your product online at [www.vtech.co.uk/warranty](http://www.vtech.co.uk/warranty)

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

**THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.**

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

Join the VTech club online at [www.vtech.co.uk](http://www.vtech.co.uk)

