



# Instruction Manual



**CoComelon™**



## Treehouse Track Set



**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **vtech** Baby

**Toys that will stimulate their interest in different textures, sounds and colours**

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

**Birth-36 months**



## **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

**3-6 years**



## **Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

**4-10 years**




To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Thank you for purchasing the **Cocomelon™ Toot-Toot Drivers® Treehouse Track Set**.

Get ready to play in and around the treehouse. Place the JJ's Off-Road Vehicle on the **SmartPoint™** locations to hear fun phrases and sounds. Then, roll the car along to the spiral track to have sliding fun.



# INCLUDED IN THE PACKAGE



One **Toot-Toot Drivers®** JJ Off-Road Vehicle



One treehouse top



One rotating antenna




One treehouse left



One treehouse right



One tree trunk left



One tree trunk right



One spiral track



One sliding track



One **SmartPoint™** treehouse platform



One **SmartPoint™** tree root plate

- Sticker sheet
- Quick Start Guide

### **WARNING:**


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

### **NOTE:**

Please save this Instruction Manual as it contains important information.

## **Unlock the Packaging Locks**

- ① Rotate the packaging locks anticlockwise several times.
- ② Pull out the packaging locks and discard.




## **GETTING STARTED**

### **Battery Removal and Installation**

#### **JJ's Off-Road Vehicle**

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



**WARNING:**

Adult assembly required for battery installation.  
Keep batteries out of reach of children.

**IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

**RECHARGEABLE BATTERIES**

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:


Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for kerbside collections.

# LABEL APPLICATION


Please securely place the stickers on the playset as indicated below:




# ASSEMBLY INSTRUCTIONS

With the CoComelon™ Toot-Toot Drivers® Treehouse Track Set, safety comes first. To ensure your child's safety, adult assembly is required.


1. Assemble and attach the **Spiral Track** to the left and right **Tree Trunk** components as shown below. A clicking sound will confirm the pieces are firmly connected.




2. Assemble and attach the **Treehouse Platform** to the **Tree Trunk** components as shown below. Listen for the clicking sound to confirm the pieces are firmly connected.




3. Assemble and attach the **Treehouse** to the **Treehouse Platform** as shown below. A clicking sound will confirm they are firmly connected.




4. Place the **Rotating Antenna** on the **Treehouse Top**, then attach the **Treehouse Top** to the left and right **Treehouse** components as shown below. Clicking sounds will confirm the top is firmly connected.



5. Assemble and attach the **Tree Root Plate** to the **Tree Trunk Left** as shown below: Make sure you hear a click sound to confirm they are firmly connected.



6. Connect the **Sliding Track** to the **Treehouse Platform** as shown below: Make sure you hear a click sound to confirm they are firmly connected.



Once you've completed the above steps, you are ready to play! You can also connect the track set to other **CoComelon™ Toot-Toot Drivers®** track sets to expand the CoComelon world (each sold separately). Recreate JJ's house and backyard by connecting the Treehouse Track Set and JJ's House Track Set (sold separately).




## PRODUCT FEATURES

### JJ's Off-Road Vehicle

#### 1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** (⏻) position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** (●) position.



#### 2. Automatic Shut-Off

To preserve battery life, **JJ's Off-Road Vehicle** will automatically switch itself off after approximately 60 seconds without input. The unit can be turned on again by pressing the character button, or triggering a **SmartPoint™** location.


**Note:** This product is in Try-Me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play. If the unit switches off while playing, we suggest installing new batteries.

# ACTIVITIES

## JJ's Off-Road Vehicle

### 1. JJ Character Button

Press the character button to hear fun sounds, songs, phrases and melodies. The light will flash with the sounds.



### 2. SmartPoint™ Locations

For added fun, **JJ's Off-Road Vehicle** interacts with the **Cocomelon™ Toot-Toot Drivers® Treehouse Track Set**. Simply place the vehicle on one of the two **SmartPoint™** locations to see the car's lights flash and to hear fun sounds or music. The car even interacts with other **CoComelon™ Toot-Toot Drivers®** track sets (sold separately).



## Treehouse Track Set

### 1. Spiral and Sliding Track

Place **JJ's Off-Road Vehicle** on the **Treehouse Platform**. Roll **JJ's Off-Road Vehicle** down and around the **Spiral Track** or down the **Sliding Track**.



# MELODY LIST

1. Incy Wincy Spider
2. Hickory Dickory Dock
3. 12345 Once I Caught a Fish Alive
4. If You're Happy and You Know It
5. This Is the Way
6. The Ants Go Marching

## SONG LYRICS

### Song 1

The ants go marching two by two.  
Hurrah, hurrah.  
The ants go marching two by two.  
Hurrah, hurrah.

### Song 2

It's better to work together,  
Because it's double the fun.  
I have fun when you have fun. Yes!  
Share when you only have one.

### Song 3

12345,  
Once I caught a fish alive.

### Song 4

Sharing makes us all happy.  
We can share.  
Sharing makes us all happy.

## Song 5

It's the animal dance,

Let's all stand up.

And move around, and clap our hands.

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

# CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## **UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)  
Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

## **Australian Customers:**

Phone: 1800 862 155  
Website: [support.vtech.com.au](http://support.vtech.com.au)

## **NZ Customers:**

Phone: 0800 400 785  
Website: [support.vtech.com.au](http://support.vtech.com.au)

# PRODUCT WARRANTY/ CONSUMER GUARANTEES

## **UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

## **Australian Customers:**

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –  
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***www.vtech.co.uk***  
***www.vtech.com.au***

