

**vtech**<sup>®</sup>  
Baby

# User's Manual

## Little Friendlies Magical Discovery Mirror



© 2016 VTech  
All rights reserved  
Printed in China  
91-003307-001 

**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **E**lectronic Learning Computers

**Cool, aspirational and inspiring computers for curriculum related learning**

### **vtech Baby**

**Toys that will stimulate their interest in different textures, sounds and colours**

#### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

### **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

#### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

#### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

**Birth-36 months**



**3-6 years**



**4-10 years**




To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Thank you for purchasing the **VTech® Little Friendlies Magical Discovery Mirror!**

Learn and discover with this adorable elephant and its magic mirror! Press the star button to magically see a lion and monkey appear on the mirror! Enjoy music and nature sounds while developing motor skills with the hanging star, butterfly and roller ball.



# INCLUDED IN THIS PACKAGE

- One VTech® Little Friendlies Magical Discovery Mirror
- Two cot attachment straps
- One user's manual


## WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

## NOTE:

Please keep this user's manual as it contains important information.

Unlock the packaging locks:




- ① Rotate the packaging locks 90 degrees anticlockwise.
- ② Pull out the packaging locks.

# GETTING STARTED

## BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 3 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance).
4. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.



Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

[www.recycle-more.co.uk](http://www.recycle-more.co.uk)

[www.recyclenow.com](http://www.recyclenow.com)

## ASSEMBLY INSTRUCTIONS


With the **VTech® Little Friendlies Magical Discovery Mirror**, safety comes first. To ensure your child's safety, do not let your child play with this toy until it has been fully assembled by an adult. Please follow the assembly instructions below carefully and make sure the final assembly is correct. Attach only to cots with sturdy rails and spindles. Do not attach to playpens with mesh walls.

Please make sure the cot attachment straps are out of reach from children when placed in the cot. Please remove the cot attachment straps from the unit if it is going to be used outside of the cot.

1. Place the unit into the cot, bringing the straps over the top rail. Slide the top of the straps under the slots on the back of the unit and secure. You can adjust the hanging height by choosing the appropriate hole on the top of the straps.



2. Tie the cord securely around the nearest spindle. Pull slightly on the unit to make sure the straps have been securely fastened. The unit should be snug against the cot rail. Please check the unit frequently to ensure it is still secure.



## PRODUCT FEATURES

### 1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** (🔊) or the **HIGH VOLUME** (🔊) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (●) position.



### 2. AUTOMATIC SHUT OFF

To preserve battery life, the **VTech® Little Friendlies Magical Discovery Mirror** will automatically shut off after approximately 60 seconds without input. The unit can be turned on again by pressing any button.

**NOTE: If the unit powers down quickly while playing, we suggest changing the batteries.**

# ACTIVITIES

1. Slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** (🔊) or **HIGH VOLUME** (🔊) position to turn the unit **ON**. You will hear a song, a playful phrase and a short tune. The lights will flash with the sounds.



2. Press the **LIGHT UP STAR BUTTON** or insert and press the **HANGING STAR** into the slot to hear playful songs, phrases, sounds and to play peek-a-boo with the animals in the mirror. The lights will flash with the sounds. Press the **LIGHT UP STAR BUTTON** several times quickly to hear fun sounds or a song.



3. Pull the **HANGING STAR** to hear playful songs, melodies, phrases and sounds. The lights will flash with the sounds. Pull the star several times quickly to hear a short tune.



4. Twist the **BUTTERFLY** to hear a phrase, short tunes and fun sounds. The lights will flash with the sounds. Twist the **BUTTERFLY** when a melody is playing to hear fun sounds play over the melody.





# MELODY LIST

1. Frère Jacques
2. A-Tisket, A-Tasket
3. Simple Simon
4. Sing a Song of Sixpence
5. Do Your Ears Hang Low?
6. Good Night Ladies
7. On Top of Old Smokey
8. My Bonnie Lies Over the Ocean
9. Here We Go Round the Mulberry Bush
10. Twinkle, Twinkle, Little Star

## SING-ALONG SONG LYRICS

### SONG 1

Look in the mirror, what do you see?  
What do you see? What do you see?  
Look in the mirror, what do you see?  
I see my best friends!

### SONG 2

My legs are strong!  
My trunk is long!  
The jungle is where I belong!

### SONG 3

Twinkle, twinkle, little star,  
How I wonder what you are.  
The monkey's swinging in the tree,  
The lion is our best buddy!  
Twinkle, twinkle, little star,  
How I wonder what you are.

# CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, install a new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

## **IMPORTANT NOTE:**

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546 810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**CLASS 1  
LED PRODUCT**

**Adult assembly required.**



# PRODUCT REGISTRATION

Visit [www.vtech.co.uk/clubvtech/login](http://www.vtech.co.uk/clubvtech/login)  
to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



## PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
9. To keep an online record of your warranty, please register your product online at [www.vtech.co.uk/warranty](http://www.vtech.co.uk/warranty)

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

**THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.**

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.