

vtech[®]
baby

Parent's Guide


2-in-1 Push & Discover Turtle



91-003985-001 

INTRODUCTION

Meet the **2-in-1 Push & Discover Turtle** by **VTech®**! This adorable little turtle and butterfly really are baby's best friends! The easy-to-grab handle is perfect for little hands and easily detaches for two ways of play. The light up Number button, Music button and Turtle & Butterfly button introduce the turtle and butterfly, counting, sounds, melodies and phrases.



INCLUDED IN THE PACKAGE

- 2-in-1 Push & Discover Turtle
- Handle
- Handle base
- Parent's Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE

Please keep this Parent's Guide as it contains important information.

Removing the Packaging Locks:




- ① Rotate the packaging lock 90 degrees anticlockwise.
- ② Pull out the packaging lock and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the bottom of the turtle. Use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.


In Australia & New Zealand:

Check with you local council for kerbside collections.


ASSEMBLY INSTRUCTIONS

With the **2-in-1 Push & Discover Turtle**, safety comes first. To ensure your child's safety, adult assembly is required.



1. Connect the **Handle Top** to the **Handle Base** as shown below. Please note that once the handle pieces are connected, they cannot be separated.



2. Attach the **Handle Base** to the turtle's body by inserting the **Handle** into the slot on the back of the turtle.






3. To remove the **Handle**, press the two buttons on either side of the **Handle Base** and pull out the handle from the back of the turtle.



PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit **On**, slide the **On/Off/Volume Switch** to the Low volume  position or the High volume  position. You will hear a song and a welcoming phrase. To turn the unit **Off**, slide the **On/Off/Volume Switch** to the **Off** ● position.



2. Automatic Shut-Off

To preserve battery life, the **2-in-1 Push & Discover Turtle** will automatically shut off after approximately one minute without input. The unit can be turned on again by pressing any button or turning the back wheel.

NOTE

If the unit repeatedly powers down while playing, please install a new set of batteries.

ACTIVITIES


1. Number Button

Press the **Number Button** to learn about numbers and practise counting with playful phrases and fun sounds. The lights will flash with the sounds.




2. Music Button

Press the **Music Button** to hear playful melodies and songs. The lights will flash with the sounds.



3. Animal Button

Press the **Animal Button** to learn about the turtle and butterfly. The lights will flash with the sounds.



4. Wheel Sensor

Push or pull the turtle with or without the handle attached to hear a variety of fun sounds and short tunes. Watch the turtle's head bob and the butterfly's wings flap up and down. The light will flash with the sounds.



MELODY LIST

1. A-Tisket, A-Tasket
2. Alphabet Song
3. Bingo
4. Ride a Cock Horse to Banbury Cross
5. Glow Worm
6. Hey, Diddle, Diddle
7. Skip to My Lou
8. Old MacDonald
9. Pease Porridge Hot
10. Row, Row, Row Your Boat

SONG LIST

Song 1

Let's go for a stroll in the sun.
Stretch your legs and have some fun!
Little butterfly stretches her wings, too.
We're ready for a great day exploring with you!

Song 2

One, two, three, four, walk with me,
I want to explore the world with you.
One, two, three, four, walk with me,
We can have fun, you and me!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the unit still does not work, install a new set of batteries.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

