

vtech[®]
baby

Instruction Manual

Busy Musical Bee



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Busy Musical Bee**. This cute and cuddly bee features soft wings with pockets, so you can flap the bee's wings! The bee also features a light up heart button which triggers responses. Press the light up heart button to hear soothing music, loving phrases and fun sounds. Bee is made from soft fabrics, made from 6 recycled plastic bottles! You can even remove the electronic module inside the bee, so you can hand wash bee to keep it fresh and clean.



• Electronic Module

• Off / Low / High Volume Switch

Light Up Heart Button



INCLUDED IN THIS PACKAGE

- **Busy Musical Bee**
- Quick Start Guide

NOTE

Please save this Instruction Manual as it contains important information.

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

WASHING INSTRUCTIONS

Please remove the electronic module before washing.

WARNING:

Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.


REMOVABLE ELECTRONIC MODULE

1. To remove the electronic module, open the Velcro-like closure on the back of the bee. Then, remove the electronic module.
2. To insert the electronic module, line up the light up heart button with the bee's heart. Then, secure the Velcro-like closure.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelee bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:



www.vtech.co.uk/recycle


www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES

1. Off / Low / High Volume Switch

To turn the unit **On**, slide the **Off / Low / High Volume Switch** located on the electronic module inside the back of the bee to the **Low Volume** () or **High Volume** () position. You will hear a sound, a phrase and a song about the bee. To turn the unit **Off**, slide the **Off / Low / High Volume Switch** to the **Off** (●) position.




2. Automatic Shut-Off

To preserve battery life, the **Busy Musical Bee** will automatically power down after approximately 25 seconds without input. The unit can be turned on again by pressing the **Light Up Heart Button**.

ACTIVITIES

1. Light Up Heart Button

Press the **Light Up Heart Button** to hear a variety of fun melodies and bee sounds. Press and hold the **Light Up Heart Button** to hear approximately 3 minutes of music play with bee sounds. The light will flash with the voice and fade in and out with the music and sounds.



MELODY LIST

1. A-Tisket, A-Tasket
2. On Top of Old Smokey
3. Can Can
4. My Pony Boy
5. One Man Went to Mow a Meadow
6. Meet Me in St. Louis, Louis
7. Glow Worm
8. Little Tommy Tucker
9. Yankee Doodle
10. In the Good Old Summertime
11. Skip to My Lou
12. Grieg - Morning Mood
13. Ride A Cock Horse to Banbury Cross
14. Funiculi, Funicula
15. Parade of the Wooden Soldiers
16. Aiken Drum
17. One, Two, Buckle My Shoe
18. Dill Pickles Rag
19. Green Grass Grew All Around
20. Roses are Red
31. I Want to Go Back to Michigan
32. Polly Put the Kettle On
33. Indiana (Back Home Again In)
34. Little Robin Redbreast
35. MacNamara's Band
36. Teddy Bears' Picnic
37. Mary Mary Quite Contrary
38. Looby Loo
39. Oats, Peas, Beans, and Barley Grow
30. Bicycle Built for Two

SONG LIST

SONG 1

Buzzing, buzzing,
I'm a buzzing busy bee,
Working hard, with my friends,
And my family!

SONG 2

I'm a happy little bee,
Flying from tree to tree,
Hugging all the flowers to make honey,
I'm as happy as can bee!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the battery if the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.
5. The bee is surface washable. Please remove the electronic module and follow the care instructions on the plush tag before cleaning.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back On. The unit should now be ready to use again.
5. If the unit still does not work, install a brand new set of batteries.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

