

User's Manual

Sit & Discover Ride On



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...



Interactive toys to develop their imagination and encourage language development

l want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

l need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years

```
To learn more about this and other VTech® products, visit www.vtechuk.com
```

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

l am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle


Birth-36 months

ntroduction

INTRODUCTION

Thank you for purchasing the $\textbf{VTech}^{\texttt{B}}$ Sit & Discover Ride On learning toy.

Cruise into the learning zone on the **Sit & Discover Ride On** by **VTech**[®]. This 2-in-1 toy has an interactive steering wheel that includes driving, learning and music modes. Turn on the engine, move the gear stick or press the horn to hear realistic driving sound effects. Choose one of six places and your child can pretend to drive to fun locations. The **Sit & Discover Ride On** also has a front activity panel with fun manipulative features and under seat storage your child can fill with small toys for more fun on the go!



INCLUDED IN THIS PACKAGE

- User's manual
- 18 screws




- 1 VTech® Sit & Discover Ride On steering wheel activity panel
- 1 vehicle body
- Handle bars
- 1 set of front wheels (includes an axle, two large brackets and two



wheels)

- 1 set of back wheels (includes an axle, two small brackets and two wheels)
- 1 seat bracket
- 1 seat

WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.




- Rotate the packing locks
 90 degrees counter-clockwise
- 2 Pull out the packing locks
- NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the bottom of the Activity Panel. Use a coin or a screwdriver to loosen the screw.
- Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- · Insert batteries with the correct polarity.
- · Do not short-circuit the battery terminals.
- · Remove exhausted batteries from the toy.
- · Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit: www.recycle-more.co.uk www.recyclenow.com

ASSEMBLY INSTRUCTIONS

With the **VTech® Sit & Discover Ride On**, safety comes first. To ensure your child's safety, adult assembly is required.

ATTENTION: The maximum weight limit for this product is 20 kg. It is not recommended for children older than 36 months.

- Insert the handle bars into the slot on the top of the vehicle body. Turn the vehicle body over and secure the handle bars with two of the screws.
- Insert the front wheels (includes an axle, two large brackets and two wheels) into the slot on the front of the vehicle body. Secure each bracket with 4 screws.
- Insert the back wheels (includes an axle, two small brackets and two wheels) into the slot on the back of the vehicle body. Slide the two brackets out to lock the axle into place. Secure each bracket with 2 screws.
- 4. Insert the seat bracket into the top of the seat.









 Put the seat bracket on the top of the vehicle body, then turn the vehicle body over and secure the seat bracket with 4 screws.

PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON**/ **OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** ((\blacksquare))) or **HIGH VOLUME** (\blacksquare)) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (\bigcirc) position.



2. MODE SELECTOR SWITCH

Slide the MODE SELECTOR SWITCH to the LEARNING MODE (abc), DRIVING MODE () or MUSIC MODE () position.



3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech[®] Sit & Discover Ride On** will automatically power-down after approximately 60 seconds without input. The unit can be turned on again by pressing any button.

ACTIVITIES

- 1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a welcoming phrase, playful sounds, short tunes and a sing-along song, depending on the selected mode. The lights will flash with the sound.
- 2. Press the **animal buttons** to hear animal names, animal sounds, names of locations around town or melodies, depending on the selected mode. The lights will flash with the sound.
- Slide the car back and forth to hear fun sounds or short tunes, depending on the selected mode. Stop sliding the car to hear fun sounds, playful phrases and short tunes, depending on the selected mode. The lights will flash with the sound.
- Push or pull the gear stick to hear fun sounds and phrases or short tunes, depending on the selected mode. The lights will flash with the sound.










5. Press the horn button to hear a variety of horn sounds and short tunes. The lights will flash with the sound.

- 6. Press the left and right arrow buttons to hear the sounds, directional phrases or short tunes, depending on the selected mode. The lights will flash with the sound.
- 7. Turn the ignition key to hear sounds and phrases or sing-along songs, depending on the selected mode. The light will flash with the sound.
- 8. Insert the Sit & Discover Ride On steering wheel activity panel onto the handle bars to hear a playful sound, short tune and phrase. By connecting the activity panel to the handle bars, the motion sensor will be activated. Turn the activity panel to hear a variety of melodies, short tunes and fun sounds. The lights will flash with the sound. Removing the activity panel from the handle bars will disable the motion sensor.











MELODY LIST:

- 1. London Bridge
- 2. Yankee Doodle
- 3. Sailing, Sailing
- 4. Clementine
- 5. Mulberry Bush
- 6. Three Blind Mice
- 7. Old McDonald
- 8. Farmer in the Dell
- 9. Chicken Reel
- 10. This Old Man
- 11. Baa, Baa, Black Sheep
- 12. Little Bo Peep
- 13. BINGO
- 14. Where Has My Little Dog Gone?
- 15. Pussy Cat, Pussy Cat
- 16. Three Little Kittens
- 17. Little Robin Red Breast
- 18. Listen to the Mocking Bird

SING-ALONG SONG LYRICS

SONG 1

Turn the key, spin the wheel, Drive the car to and fro.

SONG 2

Buckle up, we're ready to go. Don't forget to look both ways, before you go!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) with any problems and/or suggestions that you might have. A service representative will be happy to help you.





rtech PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.



- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).

Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.