

## Parent's Guide



### **Magic Lights Castle**





VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...



Interactive toys to develop their imagination and encourage language development

### l want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

#### Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

### I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years

```
To learn more about this and other VTech<sup>®</sup> products, visit www.vtech.co.uk
```

#### vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

### l am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months

### INTRODUCTION

Thank you for purchasing the VTech<sup>®</sup> Toot-Toot Friends<sup>™</sup> Kingdom Magic Lights Castle! Place Princess Poppy and Prince Louie on the MagicPoint<sup>™</sup> location to hear fun sounds and music. Press the Heart Button to open up the stairs with fun sounds and colourful lights. Celebrate and have fun with Princess Poppy and Prince Louie in this beautiful light up castle!



## INCLUDED IN THIS PACKAGE

**NOTE**: This toy is not intended for teething.

- One character Princess Poppy
- One character Prince Louie





- Two pillars
- · One ground floor base and dance floor
- One ground floor main wall



- One 1st ground floor
- One single tower roof
- One triple tower roof
- One small pillar
- One clock



- One book support cover
- One book page
- One chandelier
- One big flag
- Two small flags



- Two doors
- One cat
- One bed
- One mirror



One label sheet



• One parent's guide

### 5

#### WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

**NOTE:** Please keep this parent's guide as it contains important information.

### **GETTING STARTED**

# BATTERY REMOVAL AND INSTALLATION – Magic Lights Castle

- 1. Make sure the unit is OFF.
- Locate the battery cover on the top left of the 1st floor base. Use a screwdriver to loosen the screw.
- If used or spent batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
- Install 2 new AA (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).



5. Replace the battery cover and tighten the screw to secure.

#### **Battery Notice**

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.

- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

#### Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the

battery contains more than the specified value of mercury



(Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

### CAUTION:

Adult assembly required. For your child's safety, do not let your child play with this toy until it is fully assembled.

#### WARNING:

Once the toy is fully assembled, only the book support cover and the chandelier can be disassembled. Do not attempt to disassemble other parts of the toy as this may damage the toy.

### **ASSEMBLY INSTRUCTIONS**

With the VTech<sup>®</sup> Toot-Toot Friends<sup>™</sup> Kingdom Magic Lights Castle, safety comes first. To ensure your child's safety, adult assembly is required.

1. Insert the two **Pillars** into the **Ground Floor Base** as shown in the picture. You will hear a click when the pieces are secure.

**Note:** Carefully check the shape of pillars and ensure you are inserting them into the correct holes.



2. Insert the Ground Floor Main Wall into the Ground Floor Base as shown in the picture. You will hear a click when the pieces are secure.



3. Attach the two **Doors** to the doorframe of the **Ground Floor Base** as shown in the picture.

**Note:** Attach the upper edge of the **Door** to the upper section of the doorframe first. Then, attach the under edge of the **Door** to the under section of the doorframe.



4. Insert the **1st Floor Base** into the **Ground Floor Main Wall** as shown in the picture. You will hear a click when the pieces are secure.



 Attach the Single Tower Roof to the Triple Tower Roof to create the big tower roof.



 Insert the Small Pillar into the platform of the Triple Tower Roof as shown in the picture. You will hear a click when the pieces are secure.



7. Attach the **Clock** to the **Triple Tower Roof** as shown in the picture. You will hear a click when the pieces are secure.



- 8. Insert the big tower roof and the Small Pillar into the 1st Floor Base as shown in the picture. You will hear a click when the pieces are secure. Then, insert the triple tower roof into the holes of the staircase and press down firmly. You will hear a click when the pieces are secure.
- 9. Attach the **Book Page** to the **Book Support Cover** as shown in the picture.





10. Insert the **Book Support Cover** and the **Chandelier** into the **Triple Tower Roof** as shown in the picture.



11. Attach the three **Flags** in different sizes to the **Triple Tower Roof** as shown in the picture.



### LABEL APPLICATION









### **PRODUCT FEATURES**

#### 1. Off/Volume Switch

To turn the castle **ON**, slide the switch to either the **Low Volume** (◄)) or **High Volume** (◄))) position. To turn the castle **OFF**, slide the switch to the **Off** (●) position.

#### 2. Mode Switch

Slide the **Mode Switch** to the left to enter **Explore & Learn Mode**. Slide the **Mode Switch** to the middle to enter **Instrument Fun Mode**. Slide the **Mode Switch** to the right to enter **Music Mode**.

#### 3. Instrument Buttons

Press the six **Instrument Buttons** to learn about colours, numbers, instrument facts, to play instrument sounds and to hear music with beautiful lights.



#### 4. Heart Button

Press the **Heart Button** to hear fun sounds with beautiful lights. When the stairs are closed, press the button to open up the stairs.



#### 5. MagicPoint<sup>™</sup> Location

There is one **MagicPoint**<sup>TM</sup> located in the castle. Place the characters onto the **MagicPoint**<sup>TM</sup> location to hear fun responses.

The **MagicPoint**<sup>™</sup> location can also interact with other **VTech**<sup>®</sup> **Toot-Toot Friends**<sup>™</sup> characters (each sold separately).



#### 6. Automatic Shut Off

To preserve battery life, the **Magic Lights Castle** will automatically shut off after several minutes without input. The castle can be turned on again by sliding the **Mode Switch** to the **Explore & Learn Mode**, **Instrument Fun Mode** or **Music Mode** position.

**NOTE:** If the castle shuts off whilst playing, we suggest installing a brand new set of batteries.

### ACTIVITIES

Slide the **Off/Volume Switch** to either the **Low Volume** or **High Volume** position to turn the castle on.

1. Mode 1: Explore & Learn

Slide the **Mode Switch** to the left position to enter this mode. Press the **Instrument Buttons** to learn about colours, numbers, counting, instrument facts and more! Place the characters onto the **MagicPoint**<sup>™</sup> location to hear the characters talk, introduce themselves and sing, or press the **Heart Button** to hear fun sounds.



#### 2. Mode 2: Instrument Fun

Slide the **Mode Switch** to the middle position to enter this mode. Press the **Instrument Buttons** to hear melodies played by the different instruments. Place the characters onto the **MagicPoint**<sup>™</sup> location or press the **Heart Button** to hear fun instrument sounds with beautiful lights.



#### 3. Mode 3: Music

Slide the **Mode Switch** to the right position to enter this mode. Press the **Instrument Buttons** for piano play. Place the characters onto the **MagicPoint**<sup>™</sup> location to hear the characters sing a song or sing with the melodies together, or press the **Heart Button** to hear melodies with beautiful lights.



Here are 2 simple songs that you could play using the 6 **Instrument Buttons** in mode 3:





### MOTOR SKILL DEVELOPMENT

Explore the **Magic Lights Castle** and find all of these great manipulative features which encourage motor skill development.

1. Press the **Heart Button** to open up the stairs.



2. Close the Stairs.

3. Open and close the **Doors**.

4. Turn the Clock Hands.

5. Ring the Bells.

6. Turn the page of the **Book**.



7. Spin the Chandelier.

- Place the two characters onto the Dancing Floor and rotate the disc to see the characters dance.
- 9. Three **Accessories** are included for role play fun.





### SONG LYRICS

1. Princess Poppy

Red and Yellow, Red and Yellow, And there's Blue, And there's Blue, Orange and Purple, Orange and Purple, And Green too! And Green too!

#### 2. Princess Poppy

Come along and count with me, 1 2 3 4 5 6, Come along and count with me, Count along with me!

#### 3. Prince Louie

So many, fun colours, For us now to discover, There's green, red and blue, Orange and purple, And don't forget there's yellow!

#### 4. Prince Louie

Counting is great, you'll see, Just sing along with me, 1 2 3 4 5 6, 1 2 3 4 5 6!

#### 5. Princess Poppy

My name's Poppy, I am a Princess, All across the Kingdom, I bring joy, In my castle, I just love to sing, Come along and sing with me!

#### 6. Prince Louie

My name is Prince Louie, and I'm the bravest prince you'll ever see, Adventure forever, So won't you come join me?

### **CARE & MAINTENANCE**

- 1. Keep the unit and its metal parts clean by wiping them with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries when the unit is not in use for an extended period of time.
- 4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture or water.

### TROUBLESHOOTING

If for some reason the toy stops working or malfunctions whilst a character is on the **MagicPoint**<sup>™</sup> location, please remove the character and place them back onto the **MagicPoint**<sup>™</sup>. If the toy still does not function, or if for some reason the toy stops working or malfunctions on its own, please follow these steps:

- 1. Please turn the toy OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the toy stand for a few minutes, then replace the batteries.
- 4. Turn the toy ON. The toy should now be ready to play with again.
- 5. If the toy still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

### **CONSUMER SERVICES**

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products

and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

#### UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK) Website: www.vtech.co.uk/support

#### Australian Customers:

Phone: 1800 862 155 Website: support.vtech.com.au

#### NZ Customers:

Phone: 0800 400 785 Website: support.vtech.com.au

### Product Warranty / Consumer Guarantees

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

#### Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/ consumerguarantees for further information.



## Visit our website for more information about our products, downloads, resources and more.

### www.vtech.co.uk www.vtech.com.au



TM & © 2019 VTech Holdings Limited. All rights reserved. **Printed in China.** 91-003712-004