

User's Manual

Sleepy Glow Bear




VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

l am...

and effect

toddle



Electronic Learning

Computers


To learn more about this and other VTech® products, visit www.vtech.co.uk

Introduction

INTRODUCTION

Thank you for purchasing the VTech® Sleepy Glow Bear.

This cuddly bear will soothe baby with its soft glowing night light, melodies, songs, nature sounds and loving phrases.



INCLUDED IN THIS PACKAGE

- One VTech® Sleepy Glow Bear
- One user's manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


NOTE:

Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the electronic module inside the bear. Use a coin or a screwdriver to loosen the screw.
- Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- · Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

Product Features

PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH


To turn the unit **ON**, slide the **ON/ OFF/VOLUME CONTROL SWITCH** located on the electronic module inside the bear to the **LOW VOLUME** (◀)) or **HIGH VOLUME** (◀))) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (●) position.

2. TIMER SWITCH

Slide the **TIMER SWITCH** to the **demo/15 minute/30 minute** position. The unit is set to the demo mode position in the packaging and is only intended to play the program for approximately one minute.

3. LIGHT CONTROL SWITCH Slide the LIGHT CONTROL SWITCH to select the light off (●), low intensity (♀) or high intensity (♀) position. The light will fade in and fade out with the music and sounds. If the light starts to flicker, turn the light off then back on. If the light continues to flicker, please change the batteries.







4. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Sleepy Glow Bear** will automatically power-down after the selected time. The unit can be turned on again by pressing any button.

Note: If the unit repeatedly powers down or the light flickers then fades out, please change the batteries.

Activities

ACTIVITIES

- Slide the on/off/volume control switch to turn the unit on. You will hear a gentle sound, a phrase, lullabies and soothing melodies mixed with nature sounds. The light will fade in and out slowly with the sounds.
- Press the heart button to hear soothing phrases, lullabies and soft melodies with nature sounds. The light will fade in and out slowly with the sounds.
- Press the music button to hear soothing melodies. The light will fade in and fade out slowly with the sounds.

4. Press the nature sound button to hear a soothing phrase and soft nature sounds, some sounds are accompanied by a soothing melody. The light will fade in and fade out slowly with the sounds.



SING-ALONG SONGS LYRICS

SONG 1

Sleep well sleep well little one, Time to rest as night draws on.

SONG 2

Good night baby, Good night baby, Good night baby, It's time to go to sleep.

MELODY LIST

- 1. Are You Sleeping?
- 2. ABC Tumble Down D
- 3. Nocture Borodin
- 4. Polly Put the Kettle On
- 5. Four Seasons (Spring) Vivaldi
- 6. Bicycle Built for Two
- 7. Blue Danube Waltz Strauss
- 8. Baa Baa Black Sheep
- 9. Bear Went Over the Mountain
- 10. Spring Song Mendelssohn
- 11 Etude 3 Liszt
- 12 Beautiful Dreamer
- 13 Cradle Song
- 14 Roudou Mozart
- 15 Brahms' Lullaby
- 16 Did You Ever See a Lassie?
- 17 Morning Greig
- 18 Good Morning Merry Sunshine

- 20 Four Seasons (Winter) Vivaldi
- 21 Imprompt Schubert
- 22 Irish Lullaby
- 23 Little Miss Muffet
- 24 Grandfather's Clock
- 25 Little Robin Redbreast
- 26 Magic Flute Mozart
- 27 Clair de Lune Debussy
- 28 Fur Elise Beethoven
- 29 Oh! Susanna
- 30 Down By the Riverside
- 31 Prelude Fugue Bach
- 32 Humpty Dumpty
- 33 Boys & Girls Come Out to Play
- 34 Distanti Schumann
- 35 All Through the Night
- 36 Ring Around the Rosy
- 37 Sleeping Beauty Waltz Tchaikovsky
- 38 Sleep Baby Sleep
- 39 Almostto Schumann
- 40 White Coral Bells

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit is not in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit ON. The unit should now be ready to play again.
- 5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 01235 546810 (from UK) or +44 1235 546 810 (outside UK), and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing VTech® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on at 01235 546810 (from UK) or +44 1235 546 810 (outside UK), with any problems and/ or suggestions that you might have. A service representative will be happy to help you.





PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

- 1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- 3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- 7. Returns to VTech Electronics Europe plc should include a cheque or postal order for $\pounds1.50$ towards the cost of return postage and packaging.
- 8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
- 9. To keep an online record of your warranty, please register your product online at www. vtech.co.uk/warranty

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.