


**vtech**<sup>®</sup>  
Baby

Parent's Guide

# Lullaby Lights Lamp



91-003851-001 

**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **vtech** Baby

**Toys that will stimulate their interest in different textures, sounds and colours**

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

*Birth-36 months*



## **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

*3-6 years*



## **Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


*4-10 years*



To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Soothe your baby to sleep with the **Lullaby Lights Lamp** by **VTech®**. This magical rotating lamp and light projector is ocean themed for your little one's enjoyment. As your baby goes to sleep they can watch their ocean friends swim around the lamp, or watch the soft light patterns glow onto the ceiling from the projector.



# INCLUDED IN THIS PACKAGE

- One VTech® Lullaby Lights Lamp
- One Parent's Guide


## WARNING:

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.


## NOTE:

Please keep this Parent's Guide as it contains important information.

## Removing the packaging locks:



- ① Turn the packaging lock anticlockwise several times.
- ② Pull out and discard the packaging lock.




- ① Rotate the packaging lock anticlockwise 90 degrees.
- ② Pull out and discard the packaging lock.

# BATTERY REMOVAL AND INSTALLATION


## Lullaby Lights Lamp

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the **Lullaby Lights Lamp**. Use a screwdriver to loosen the screw and open the battery cover.
3. If used or spent batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 3 AA batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure the battery cover.



## Remote Control

1. Locate the battery cover on the back of the **Remote Control**. Use a screwdriver to loosen the screw.
2. If used or spent batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
3. Install 2 new AAA batteries following the diagram inside the battery box.



4. Replace the battery cover and tighten the screw to secure.

## BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metal-hydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.



### Disposal of batteries and product

The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on

the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

[www.recycle-more.co.uk](http://www.recycle-more.co.uk)

[www.recyclenow.com](http://www.recyclenow.com)

## PRODUCT FEATURES


### 1. On/Off Button

Press the ON/OFF Button to turn the unit on and to hear 3 sing-along songs and 20 soothing melodies. Press the ON/OFF Button again to switch the unit off.



### 2. Timer Switch

Slide the Timer Switch to select the desired shut off time. Once the chosen time has finished, the unit will enter sleep mode. Choose from 10, 20 or 30 minutes.



### 3. Volume Buttons

To adjust the volume, press the **Low Volume Button** (🔊) or the **High Volume Button** (🔊)).



### 4. Night Light Button

Press the Night Light Button to set the light projector, light up the lamp or to turn off the lights.



### 5. Mode Buttons

There are 3 Mode Buttons; Lullabies, Nature Sounds and White Noise. Press one of the three Mode Buttons to choose a mode of play.



### 6. Automatic Shut-Off

To preserve battery life, the **VTech® Lullaby Lights Lamp** will automatically power down after the selected time or after it has been paused for 1 minute. The unit can be turned on again by pressing any button or when the sound sensor detects baby's cry.



## 7. Sound Sensor

The **VTech® Lullaby Lights Lamp** is equipped with a special sound sensor. Once the selected time setting has ended, the unit will automatically power down. The sensor will reactivate the program when it detects baby's cry for approximately 4 seconds without interruption. The unit will reactivate and play lullabies and nature sounds.

## 8. Remote Control

The Remote Control can start, pause and control the volume within a 30 feet straight-line distance of the lamp's Remote Control Sensor. Ensure there are no obstructions directly between the Remote Control and the lamp's Remote Control Sensor. The Remote Control is disabled after 12 hours without input.



## 9. Remote Control Sensor

The **Lullaby Lights Lamp** features a Remote Control Sensor which can receive the signal from the Remote Control.



## 10. Reactivating the Unit

The unit can be reactivated by pressing any button, by using the Remote Control (if used within 12 hours of going into sleep mode) or when the sound sensor is activated by your baby's cry.

**NOTE:**

This product is in Try me mode in the packaging. After opening the package, the unit will enter its normal mode of play. If the unit repeatedly powers down, we suggest changing the batteries.

## ACTIVITIES

1. Press the ON/OFF Button to turn the unit on. You will hear 3 soothing songs and 20 melodies. The lamp and 4 multicoloured lights will fade in and out slowly with the sounds.



2. **Lullabies Button**

Press the Lullabies Button to hear 3 soothing songs followed by soft melodies. Press the Lullabies Button again to hear the next song or melody. The lamp and 4 multicoloured lights will fade in and out slowly with the sounds.



3. **Nature Sounds Button**

Press the Nature Sounds Button to hear a combination of soothing nature sounds. Press the Nature Sounds Button again to hear the next sound pattern. The lamp and 4 multicoloured lights will fade in and out slowly with the sounds.



#### 4. White Noise Button

Press the White Noise Button to hear white noise and other sounds. Press the White Noise Button again to hear the next sound. The lamp and 4 multicoloured lights will fade in and out slowly with the sounds.



#### 5. Play/Pause Button on the Remote Control

Press the Play/Pause Button on the Remote Control to pause the sounds. Press it again to restart the sounds. If the unit is reactivated within 1 minute, the sing-along song, melody or soothing sounds will continue. However, if the unit is paused for more than 1 minute, when reactivated you will hear different responses.



#### 6. Volume Buttons on the Remote Control

Press the **High Volume Button** (speaker icon with three sound waves) to increase the volume, or press the **Low Volume Button** (speaker icon with one sound wave) to decrease the volume.



## 7. Light Control Button on the Remote Control

Press the Light Control Button to turn just the lamp projection ON. Press it again to turn the light projection OFF and to turn the lamp ON. Press it a third time to turn all of the lights OFF.



## MELODY LIST

1. Brahms - Lullaby
2. Schubert - Ave Maria
3. All Through the Night
4. Mozart - Cradle Song
5. Chopin - Berceuse, Op 57
6. Tchaikovsky - Swan Lake Waltz
7. Chopin - Nocturne op.9 No.2
8. Brahms - Berceuse
9. Vivaldi - Four Seasons (Summer)
10. Pachelbel - Canon In D
11. Bach - Air on the G String
12. Beethoven - Minuet in G Major
13. Schumann - Kinderszenen
14. Mozart - Piano Sonata No. 10
15. Peas Porridge Hot
16. Beethoven - Ode To Joy
17. Mozart - Marche Turque

18. Ride a Cock Horse to Banbury Cross
19. Schumann - Of Foreign Lands and People
20. Mozart - Piano Sonata No.16
21. Haydn - Serenade
22. Beethoven - Moonlight Sonata
23. Vivaldi - Four Seasons (Winter)
24. Home Sweet Home
25. Beautiful Dreamer
26. Diddle Diddle Dumping
27. Down By the Riverside
28. Oats, Peas, Beans and Barley Grow
29. Debussy - Clair de Lune
30. Beethoven - Fur Elise
31. Bach - Cello Suite No. 1 in G Major
32. Bach - Jesu, Joy of Man's Desiring
33. Strauss - Blue Danube Waltz
34. Hush Little Baby
35. Cockles & Mussels
36. Rock A Bye Baby
37. Bicycle Made for Two
38. Tchaikovsky - The Nutcracker Suite
39. Pussy Cat Pussy Cat
40. There's Music In The Air

# SING-ALONG SONG LYRICS

## SONG 1

Sleepy, sleepy, little one,  
Now it's time to slumber on.

## SONG 2

Close, close, close, your eyes,  
Gently go to sleep.  
Sweetly, softly, sweetly, softly.  
Baby dreams and dreams.

## SONG 3

Watch your sea animal friends,  
They are swimming around the light.  
Quietly, quietly, you'll fall asleep.

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help.



# CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

Australian Customers:

Phone: 1800 862 155

Website: [support.vtech.com.au](http://support.vtech.com.au)

NZ Customers:

Phone: 0800 400 785

Website: [support.vtech.com.au](http://support.vtech.com.au)

# PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

Australian Customers:

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.



**Visit our website for more  
information about our products,  
downloads, resources and more.**

***www.vtech.co.uk***  
***www.vtech.com.au***



TM & © 2020 VTech Holdings Limited.  
All rights reserved.  
**Printed in China.**  
91-003851-001 