



# Put & Take Dumper Truck



© 2015 VTech Printed in China 91-003006-000 (%)

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

choo

Interactive toys to develop their imagination and encourage language development

## Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

# I need...

- ...challenging activities that can keep pace with my growing mind
- ...intelligent technology that adapts to my level of learning
- National Curriculum based content to support what I'm learning at school

#### I want...

- ...to get ready for school by starting to learn the alphabet and counting
- ...my learning to be as fun, easy and exciting as can be
- ...to show my creativity with drawing and music so my whole brain

# lam...

vtech Bally

Toys that will

...responding to colours, sounds and textures

stimulate their interest

in different textures, sounds and colours

- ...understanding cause and effect
- ...learning to touch, reach, grasp, sit-up, crawl and toddle








# INTRODUCTION

Thank you for purchasing the VTech® Put & Take Dumper Truck.

The **Put & Take Dumper Truck** is an adorable learning toy for little ones to enjoy! Pop a colourful rock into the magic hole on this cute dumper truck to hear numbers and press the chunky buttons to learn colours and tools. Tip the truck to play again! Push or pull the truck to trigger fun melodies and sound effects.



# INCLUDED IN THIS PACKAGE

- One VTech® Put & Take Dumper Truck
- One user's manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and

should be discarded for your child's safety.

NOTE: Please keep this instruction manual as it contains

important information.

Unlock the packaging locks:



- ① Rotate the packaging locks 90 degrees counter-clockwise.
- ② Pull out the packaging locks.

# GETTING STARTED

## BATTERY INSTALLATION

- Make sure the unit is turned OFF.
- Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
- Install 2 new 'AAA' (LR03/AM-4) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



#### **BATTERY NOTICE**

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

#### Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005. Help protect the environment by disposing of your

product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

# PRODUCT FEATURES


#### 1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the ON/OFF/
VOLUME CONTROL SWITCH to the
LOW VOLUME ( → )) ) or the HIGH
VOLUME ( → ))) position. To turn the unit
OFF ( → ), slide the ON/OFF/VOLUME
CONTROL SWITCH to the OFF ( → )
position.



#### 2. PULL CORD

To convert the unit from a push toy to a pull toy, remove the pull cord from the storage compartment on the botton of the **Put & Take Dumper Truck**. For your child's safety we suggest you store the pull cord in the compartment until your child is walking.



#### 3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Put & Take Dumper Truck** will automatically power-down after approximately 50 seconds without input. The unit can be turned on again by any input.

# **ACTIVITIES**

 Slide the ON/OFF/VOLUME CONTROL SWITCH to turn the unit ON. You will hear a horn sound, a song and an encouraging phrase. The light will flash with the sounds.



Put the rocks into the magic hole to hear fun sounds and phrases. The light will flash with the sounds.



3. Press the **Light-up button** to hear fun phrases and songs. The light will flash along with the music.



 Press the Green button to hear the object name, colour and tunes. The light will flash along with the music.



 Press the Blue button to hear the object name, colour and tunes. The light will flash along with the music.



Push or pull the truck to hear fun melodies and phrases and see the bucket joggle up and down. The light will flash with the sounds.



Push the lever on the side of the truck to dump the rocks out of the bucket.



8. If there is no input after approximately 6 seconds, some fun sounds will be played. After another 6 seconds of no input, you will hear some fun sounds. If there is no input for a further 6 seconds, it will play a short ending tune and the unit will go into sleep mode. The unit can be re-activated by pressing any button, putting a rock into the hole or rolling the truck.

#### MELODY LIST

- 1. Hey Diddle Diddle
- Skip to My Lou
- 3. Muffin Man
- 4. Jack and Jill
- 5. A-Tisket, A-Tasket
- 6. Here We Go 'Round the Mulberry Bush
- 7. London Bridge
- 8. Polly Wolly Doodle
- 9. Yankee Doodle
- 10. Oh, Where, Oh, Where Has My Little Dog Gone?

#### SING-ALONG SONG 1 LYRICS

I'm a powerful dumper truck!
I rumble down the road moving my load from here to there!

#### SING-ALONG SONG 2 LYRICS

I am strong, there's lots I can carry. I fill up my bucket and we can go!

## **CARE & MAINTENANCE**

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# **TROUBLESHOOTING**

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 01235 546810 (from UK) or +44 1235 546 810 (outside UK), and a service representative will be happy to help you.

#### **IMPORTANT NOTE:**

Creating and developing **VTech** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on at 01235 546810 (from UK) or +44 1235 546 810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.





# vtech<sup>®</sup> PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.



- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- 2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).

Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.