

vtech[®]
Baby

User's Manual

Alfie Lullaby Comforter



© 2012 VTech

Printed in China

91-002615-000 (英)

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtechuk.com

INCLUDED IN THIS PACKAGE

Thank you for purchasing the **VTech® Alfie Lullaby Comforter** learning toy.

Get ready to shake, cuddle and sing with the **VTech® Alfie Lullaby Comforter!** This super cute comforter is made of soft tactile fabric – perfect for cuddling! It also plays soft phrases, sound effects and songs to soothe baby. If baby gently shakes the bear, the motion sensor will play a variety of fun responses.



INCLUDED IN THIS PACKAGE

- One VTech® Alfie Lullaby Comforter learning toy
- One instruction manual


WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new 'AAA' (LR03/AM-4) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.

- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.


For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

ASSEMBLY INSTRUCTIONS


Locate the flat cord on the bear and thread through the holes on the blanket and fasten. The blanket is machine washable. The bear's head is surface washable only.



PRODUCT FEATURES

1. ON/OFF BUTTON

To turn the unit **ON** (⏻) or **OFF** (●), push the ON/OFF switch (⏻). The ON/OFF switch is located inside the bear's head.




2. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Alfie Lullaby Comforter** will automatically power-down after approximately 2 minutes without input. The unit can be turned on again by pressing any buttons. Please note, activating the motion sensor will not turn the unit back on.

ACTIVITIES

1. Slide the **ON/OFF** switch to turn the unit on. You will hear a sing-along song and fun phrase. The light will flash with the sounds.



2. Press the Music Button to hear a variety of sing-along songs, melodies and sounds. The light will flash with the sounds.



3. Activate the motion sensor to hear a variety of melodies. The light will flash with the sounds.



MELODY LIST

1. A-Tisket A-Tasket
2. Jack and Jill
3. Rock-a-bye Baby
4. Toyland
5. Cradle Song
6. Row, Row, Row Your Boat
7. Oh, Dear What Can the Matter Be?
8. La Lettrelise (Beethoven)
9. Home Sweet Home
10. Beautiful Dreamer
11. London Bridge
12. Bicycle Built For Two
13. Little Boy Blue
14. Where Has My Little Dog Gone?
15. Sleeping Beauty Waltz
16. Jack Be Nimble
17. Air (Bach)
18. Three Little Kittens
19. Minuet
20. Piano Concerto A 3rd Movement
21. Au Clair de la Lune
22. Humpty Dumpty
23. Morning (Peer Gynt Suite, Grieg)
24. Prelude in A (Chopin)
25. Teddy Bear's Picnic

SONG LYRICS

SUNG SONG 1

Twinkle, twinkle, little star,
how I wonder what you are...

SUNG SONG 2

Boys and girls,
come out to play,
the moon does shine bright as day.

SUNG SONG 3

There was a farmer had a dog,
and bingo was his name-o!

SUNG SONG 4

Mary had a little lamb,
its fleece was white as snow...

SUNG SONG 5

Hold me close,
I like to cuddle,
I feel loved,
when we snuggle.

CARE & MAINTENANCE

1. Only the surface of the bear head can be washable due to the inner electronic mechanism. The blanket is machine-washable, please detach it from the bear head before washing.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit ON. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**CLASS 1
LED PRODUCT**



vtech®

PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

