



Splash and Count Penguin



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

chool

Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

vtech Bally

Toys that will stimulate their interest in different textures, sounds and colours

lam...

- ...responding to colours, sounds and textures
- ...understanding cause and effect
- ...learning to touch, reach, grasp, sit-up, crawl and toddle

I want...

- ...to get ready for school by starting to learn the alphabet and counting
- ...my learning to be as fun, easy and exciting as can be
- ...to show my creativity with drawing and music so my whole brain develops

I need...

- ...challenging activities that can keep pace with my growing mind
- ...intelligent technology that adapts to my level of learning
- ...National Curriculum based content to support what I'm learning at school

Birth-36 months






INTRODUCTION

Thank you for purchasing the VTech® Splash and Count Penguin!

Splish and splash in the bath with mummy penguin and her 10 little babies! Each baby penguin easily fits into mummy penguin's tummy and pushing the big feet button releases them back in to the water. The baby penguins will say their numbers to help your child become familiar with counting. Press the light-up star button to hear music! A fishing net is included and is perfect for scooping up the babies from the bath and also for storing them.



INCLUDED IN THIS PACKAGE

- One mummy penguin



One fishing net



- Ten baby penguins



- One instruction manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this instruction manual as it contains important information.

Unlock the packaging locks:



- ① Rotate the packaging locks 90 degrees counter-clockwise.
- 2 Pull out the packaging locks.

Please cut and discard the cord between the mummy penguin and the baby penguin before playing with this toy. This cord is not part of the product and should be discarded for your child's safety.




INSTRUCTIONS

BATTERY INSTALLATION

- Make sure the unit is turned **OFF** and the battery cover, battery box and unit are all dry.
- Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the two screws and unlock the fastener.



 Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)



4. When closing the battery cover ensure that the two screws are tightened securely. This will avoid any water leakage.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

PRODUCT ASSEMBLY

1. Choose a location on the wall next to the bath where the VTech® Splash and Count Penguin can be mounted securely. The area should be clean and dry before suctioning the unit to the wall. For better suction, we suggest wetting the suction cups before attaching the unit to the wall. Once the unit is fastened to the wall, test the strength of the suction by pulling gently on the unit. The suction cups may not stick properly to some textured tiles.



 To remove the unit from the wall, pull on the tabs on the back of the suction cups. We recommend that the unit be removed from the wall after each use as the strength of the suction cups cannot support prolonged use.



PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the ON/
OFF/VOLUME CONTROL SWITCH
to the LOW VOLUME (◄)) or HIGH
VOLUME (◄)) position. To turn the
unit OFF, slide the ON/OFF/VOLUME
CONTROL SWITCH to the OFF (♠)
position.



2. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Splash and Count Penguin will automatically power-down after approximately 45 seconds without input. The unit can be turned on again by pressing any button or by inserting a baby penguin.

WARNING:

- Batteries must be changed by an adult.
- We do not recommend submerging the unit in the water.
- This product cannot be used in salt water.
- This product should only be operated in water when fully assembled in accordance with the instructions.
- To prevent drowning, never leave a child unattended in the bath.

- Use a thermometer to check the temperature of the water before sitting a child in the bath. Toddlers have very sensitive skin and can burn easily if the water is too hot.
- Please check the suction cups periodically as they may detach after prolonged use.
- Children should not play with the suction cups when the unit is fastened to the wall as the unit may detach and cause injuries.

ACTIVITIES

 Slide the on/off/volume control switch to turn the unit on. You will hear a fun song and a playful phrase. The light will flash with the sounds.




Press the light-up music note button to hear a sing-along song or a random melody. The light will flash with the sounds.




 Insert the baby penguins into the slot on the mummy's tummy, you will hear the number on the baby penguin's tummy identified, a fun phrase or a melody. The light will flash with the sounds.



 Press the mummy's feet to release the baby penguins. You will hear a fun phrase and a short tune. The light will flash with the sounds.



If there is no baby inserted into the mummy's tummy, press the feet to hear a random question. Insert the baby penguins to answer the question. The light will flash with the sounds.



MELODY LIST

- 1. Row, Row, Row Your Boat
- 2. One, Two, Buckle My Shoe
- 3. My Bonnie Lies Over the Ocean
- 4. Chicken Reel
- 5. Sailing, Sailing
- 6. This Old Man
- 7. Alouette
- 8. Jack and Jill
- 9. Turkey in the Straw
- 10. For He's a Jolly Good Fellow

SING-ALONG SONG LYRICS

SONG 1 (to the tune of 'Ten Little Indians')

One little, two little, three little penguins.

Four little, five little, six little penguins.

Seven little, eight little, nine little penguins.

Ten little penguin babies!

SONG 2 (to the tune of 'London Bridge')

Hopped into my mummy's arms,

Where it's safe, and it's warm.

Playing with my mum is fun.

She loves me!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Make sure to empty the water out of all the elements of the unit and rinse thoroughly before drying so no sediment or cleaning products are left on the unit.
- 4. Make sure to dry all the elements of the unit before storing.
- Remove the batteries when the unit is not in use for an extended period of time.
- 6. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON.** The unit should now be ready to play again.
- If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.





vtech PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.



- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- 2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).

Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.