vtech®

Instruction Manual

Trotting Tunes Hobby Horse



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months

Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **Trotting Tunes Hobby Horse** by **VTech**®! You set the pace, let's hop, skip and gallop to hear exciting songs and music while learning about your new pony friend!



INCLUDED IN THIS PACKAGE


- One **Trotting Tunes Hobby Horse**



- One Stick



- One Non-Scuff Tip



- One Quick Start Guide

WARNING:
All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.


NOTE: Please save this Instruction Manual as it contains important information.

CAUTION:
Adult assembly required. For your child's safety, do not let your child play with the toy until it is fully assembled.

WARNING:
Adult assembly required for battery installation.
Keep batteries out of reach of children.

GETTING STARTED

Battery Removal and Installation



1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box (for best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.



Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.


Learn more at:
www.vtech.co.uk/recycle
www.vtech.com.au/sustainability
* Visit www.recyclenow.com to see a list of collection points near you.

ASSEMBLY INSTRUCTIONS

NOTE: Adult assembly required.


1. **Attach the Horse to the Stick**

   Line up the **Horse's** locking pin with the hole on the **Stick**. Press the pin and slide the **Horse** onto the **Stick** until you hear a click, showing it's securely locked in place.



2. **Connect the Stick to the Non-Scuff Tip**

   Match the locking pin on the **Non-Scuff Tip** with the hole at the base of the **Stick**. Press the pin, slide the **Non-Scuff Tip** into place, and listen for a click to confirm it's securely locked.



3. **Ready to Ride**

   When you're ready to go, hold the **Reins** and ride!



PRODUCT FEATURES

1. **Off/Mode Switch**

   Slide the **Switch** to the top to turn the unit **Off** (⭕), or down to choose a mode of play. Choose **Music Time Mode** (🎶) or **Learning Fun Mode** (🐴) to get started!



2. **Motion Sensor**

   As you ride, the **Horse** responds with galloping sounds and cheerful music.



3. **Star Button**
   Press the **Light Up Star Button** for **Horse** sound effects, music and fun phrases.



4. **Automatic Shut-Off**
   To preserve battery life, the **Trotting Tunes Hobby Horse** will shut **Off** automatically after approximately 50 seconds of inactivity. The unit can be turned **On** again by sliding the **Off/ Mode Switch** or by pressing the **Light Up Star Button**.

NOTE: If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. **Music Time Mode** 🎶
   Press the **Light Up Star Button** or ride the **Horse** to hear music, fun phrases and sound effects.
   Change the pace of the music by riding **Fast** or **Slow**.

2. **Learning Fun Mode** 🐴
   Press the **Light Up Star Button** or ride to hear fun **Horse**, phrases and sound effects like trotting, neighing and more.

SONG LYRICS

Song 1
Walking walking, trot trot trot.
Running to the stable.
Running to the stable.
Time to rest, now let's walk.

Song 2
I love to work out on the farm,
Let's herd the sheep into the barn.
We'll help the farmer move the hay,
The sun is out a perfect day.
Working on the farm.

Song 3
Come and lend a helping hand,
We'll walk the fence and tend the land.
The sun is bright, the grass is tall.
Let's head out to work! Yeehaw!

Song 4
We can jump and we can play,
We can run as fast as day.
Follow me I'll set the pace,
Horse and rider win the race!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please call our Consumer Services Department, and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech**® products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES
Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk
www.vtech.com.au

© 2025 VTech.
All rights reserved.
IM-588400-001
Version: 0