Disney · PIXAR

TOY STORY 5

vtech®

Instruction Manual

BUZZ LIGHTYEAR GAME & GO



©Disney/Pixar
www.disney.com

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

Birth-36 months

3-6 years

4-10 years








To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Disney·Pixar Toy Story 5 Buzz Lightyear Game & Go!**

Buzz Lightyear is here, ready for a challenge! Level up your little one's preschool skills with 6 activities: 5 action-packed games exploring letters, numbers, shapes, counting and more, plus animated introductions to Buzz Lightyear and his friends. Designed with first time gamers in mind, Buzz Lightyear Game & Go features simple controls and endless gaming fun with the dynamic light effects as Buzz and the other Toy Story 5 friends guide you through the adventure!



INCLUDED IN THE PACKAGE

- One **Buzz Lightyear Game & Go**
- 3 AAA batteries for demo purposes only
- Quick Start Guide


WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.

Unlock the Packaging Locks:




① Turn the packaging locks several times anticlockwise.

② Pull out and discard the packaging locks.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.



4. Install 3 new 1.5V AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.

⚠ WARNING:
Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.


In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:
www.vtech.co.uk/recycle
www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

TO BEGIN USING BUZZ LIGHTYEAR GAME & GO

HOW TO EXIT TRY ME MODE



If you've just taken the **Buzz Lightyear Game & Go** out of the packaging for the first time, you need to disable Try Me Mode before playing.
To disable Try Me Mode, press the On/Off Button to turn the unit on, and then slide the volume switch to the low position, it will enter normal play mode.

TURN ON THE UNIT

Press the On/Off button to turn the unit ON and enter normal play mode, where Buzz Lightyear will greet you. Press the Game buttons to enter the corresponding game.

Note: The included batteries are for demo use only. We recommend replacing the included batteries with new batteries before using **Buzz Lightyear Game & Go.**

BATTERY STATUS

When the batteries are exhausted, the low battery icon will be displayed and the unit will automatically shut off. Please replace the batteries with a full set of new batteries before further use.

AUTO POWER OFF

To preserve battery life, **Buzz Lightyear Game & Go** will automatically power off if there is no operation for a period of time.

PRODUCT FEATURES

Buttons Description

1. On/Off Button

Press this button to turn the unit on or off.

2. Game Buttons

Press these buttons to start a game.

3. A or B Button

Press these buttons to confirm a selection or interact with games.

4. Direction Buttons

Press these buttons to make a selection or interact with games.


5. Volume Switch

Slide the switch to set Low or High volume.


ACTIVITIES

1. Buzz and Friends

Once the unit has been turned ON, press the Direction Buttons or A and B Button to view fun animations of the characters from Toy Story 5.




2. Alphabet Balloons



Select a letter to view the letter with vocabulary animations and hear the letter sounds. You can also select to start a mission.

Woody is delivering a secret message to Buzz using some floating letter balloons. Remember the letter shown on the balloon at the beginning, and each time that letter appears, press the A or B Button to blast the balloon.


3. Counting Challenge



Select a number to view collections of objects and hear them counted aloud. You can also select to start a mission.

The horses keep running in and out of the box! Buzz is having some trouble counting the horses and he needs your help! Keep a clear eye on how many horses you think there are in the box as they keep coming in and going out. Press the Direction Buttons to select a number and press the A or B Button to confirm your selection.


4. Shape Catch



Select a shape to hear about its special features. You can also select to start a mission.


Help Buzz collect blocks of different shapes to build a toy house for Bonnie. As the blocks drop down from the top of the screen, press the Direction Buttons to control Buzz and collect the correct shapes as quickly as possible.

5. Logic Crane



The Hi-Tech Edition Buzz toys want to activate the tower crane so they can get to higher ground and see above the cloud cover to follow the North Star. Observe the pattern on the screen and fill in the missing code. Press the Direction Buttons to choose a code and press the A or B Button to confirm your selection.

6. Buzz to the Rescue



Jessie and Bullseye are lost! Buzz needs to find the missing friends, but there are many obstacles on the way and he will need your help to avoid them. Press the A or B button to make Buzz jump, and press the Down button to make him duck. The Up button can also make Buzz jump.

7. Screen Contrast Setting

Press and hold the Right button, then press the On/Off button to turn on the unit. This will activate the Screen Contrast Menu. Use the Direction Buttons to adjust the screen's contrast, and press the A or B Button to confirm the setting and then enter the opening animation.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

CONSUMER SERVICES

Creating and developing **VTech**® products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES
Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk
www.vtech.com.au

© 2026 VTech.
All rights reserved.
IM-593800-001
Version: 0