vtech®

Instruction Manual

Toot-Toot Drivers®

Chug & Learn Train Set



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Toot-Toot Drivers® Chug & Learn Train Set**.

All aboard! Chug along the tracks and activate two **SmartPoint™** locations to discover early language skills. This train station play set includes two carriages and working gates that open and close – perfect for pretend play adventures!

SmartPoint™ Locations



SmartPoint™ Locations

Station

SmartPoint™ Train



INCLUDED IN THE PACKAGE




One **SmartPoint**™ Train




Train Station



One Gate




One **SmartPoint**™ Train Station Track




One **SmartPoint**™ Track




Four Two-Colour Curved Connector Tracks **C**



Four Curved Joint Tracks **E**



Two Gate switches
(Colours may vary)



One Train Switch **G** + One Train Switch **H**
(Colours may vary)



Sticker Sheet

- One Quick Start Guide

WARNING


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

If there are no locks inside the package, disregard this message.

Removing the Packaging Locks:



① Turn the packaging locks anticlockwise several times.

② Pull out the packaging locks and discard.

⚠ WARNING:


Adult assembly required for battery installation.

Keep batteries out of reach of children.

INSTRUCTIONS

Battery Removal and Installation – Train

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).



5. Replace the battery cover and tighten the screw to secure.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.



Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:
www.vtech.co.uk/recycle
www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.


LABEL APPLICATION

Please stick the labels to the play set securely as indicated on the following page:





The four stickers in the passenger carriage can be freely placed by selecting from options 6 and 7.



There are a total of 8 stickers for the passenger carriage wheels, with 4 stickers applied to each carriage.

ASSEMBLY INSTRUCTIONS


With the **VTech® Toot-Toot Drivers® Chug & Learn Train Set**, safety comes first. To ensure your child's safety, adult assembly is required.


Assemble and attach the track components following the steps as below:

1. Attach the **Gate** to the **SmartPoint™ Train Station Track**, then attach the **SmartPoint™ Train Station Track** to the train station.




2. Place the **Red Gate Switch** on the **Yellow Train Switch Track** and the **Yellow Gate Switch** on the **Red Train Switch Track**.





All pieces have now been assembled. Please refer to the below configuration to finish the train track.


Main Configuration



PRODUCT FEATURES

1. **On/Off Switch**

   To turn the unit **On**, slide the **On/Off Switch** to the **On** (⏻) position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** (●) position.



2. **Automatic Shut-Off**


   To preserve battery life, the **Train** will automatically power-down after approximately **60** seconds without input . The unit can be turned on again by pressing the **Light Up Face Button**, rolling the **Train** quickly or triggering a **SmartPoint**™ location.

Note: If the unit powers down while playing, we suggest changing the batteries.

ACTIVITIES

Train

1. Slide the **On/Off Switch** to the **On** position. You will hear fun phrases, sounds and one song. The light will flash with the sounds



2. Press the **Light Up Face Button** to hear fun phrases, songs, sounds and melodies. The light will flash with the sounds. While a melody is playing, push the **Train** to add in fun sounds on top of the melody.



3. Push the **Train** to hear fun sounds. The light will flash with the sounds.



4. For added fun, the **Train** interacts with the **Toot-Toot Drivers® Chug & Learn Train Set**. Simply put the **Train** on one of the play set's two **SmartPoint™** locations to see the **Train's** light flash and hear fun sounds, short tunes and phrases. The **Train** even interacts with other **Toot-Toot Drivers®** play sets (each sold separately.)



Chug & Learn Train Set

1. Place the **Train** or any **SmartPoint**™ vehicle (each sold separately) on one of the play set's two **SmartPoint**™ locations to trigger fun sounds, songs or phrases.



2. Push the **Train** along the train tracks for pretend play.



3. Move the **Switch Gates** to choose different routes.



MELODY LIST

1. Aiken Drum
2. Entertainer
3. Yankee Doodle
4. Humpty Dumpty
5. Jack and Jill
6. London Bridge

SONGS

Song 1

Let's explore and play!
Down by the station,
"Tickets, please!" ready to go!
Chugga-chugga, we're on our way,
Adventures await, hooray!

Song 2

Here we go down the railway track,
The wheels are turning, clickety-clack!
Hear the whistle blow, ''Toot-toot!"
All aboard the train today!

Song 3

Toot-Toot Drivers!
(Toot-Toot Drivers!)
I'm a Toot-Toot Drivers! Shiny train.
Rolling on the long tracks (Toot-Toot!).
Taking you on a fun ride,
Let's Go! Go! and see. (Toot-Toot!)

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit Off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit On. The unit should now be ready to play with again.
5. If the unit is not working properly, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech**® products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES
Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk
www.vtech.com.au

© 2025 VTech.
Tous droits réservés.
IM-588600-000
Version:1