

Instruction Manual



Fix and Fuel Garage



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

lam...

vtech Bay

Toys that will

...responding to colours. sounds and textures

stimulate their interest

in different textures. sounds and colours

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle


Birth-36 months





INTRODUCTION

Thank you for purchasing the **Toot-Toot Drivers® Fix and Fuel Garage** by **VTech®**. Repair, fuel up, wash and race all in one place. This multi-level garage is the best place in town to get your speedy Stock Car in tip-top shape!



INCLUDED IN THE PACKAGE



One SmartPoint[™] stock car



One ground floor base



One ground floor support



One main support



One **SmartPoint**™ car wash base



One car wash roller



Two car wash supports



Sliding track E



Four sliding tracks (A, B, C, D,)



One first floor platform



One **SmartPoint**™ repair lift



One first floor support



One second floor platform



One **SmartPoint**™ tuning station plate



One tuning station roof



One tuning station support



One exit gate support



One exit gate roof



One exit gate handrail



One road sign



One track splitter



One fuel stop



One spinning plate



One floor sign plate



One floor sign support



Five screws

- Label Sheet
- · Quick Start Guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.

CAUTION

This package contains small screws. Adult assembly required.

For your child's safety, do not let your child play with the toy until it is fully assembled.

If there are no locks inside the package, disregard this message.

Removing the Packaging Locks:

- 1 Turn the packaging locks anticlockwise several times.
- 2 Pull out the packaging locks and discard.



INSTRUCTIONS

Battery Removal And Installation

- Make sure the unit is turned OFF.
- Locate the battery cover on the bottom of the Stock Car. Use a screwdriver to loosen the screw and then open the battery cover.
- 3. If used batteries are present, remove from the unit by pulling up on one end of each battery.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
- 5. Replace the battery cover and tighten the screw to secure.



Adult assembly required for battery installation.

Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.



- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product

or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:


Visit www.recyclenow.com to see a list of collection points near you.


In Australia & New Zealand:

Check with your local council for kerbside collections.

LABEL APPLICATION

Please stick the labels to the play set as shown below:





ASSEMBLY INSTRUCTIONS

With the **Toot-Toot Drivers® Fix and Fuel Garage**, safety comes first. To ensure your child's safety, adult assembly is required.

 Assemble and attach the car wash and ground floor components following the steps below:


A. Insert the two Car Wash Supports into the Car Wash Base, as shown below. Make sure you hear a click sound to confirm the supports and base are firmly connected. Then insert the Car Wash Roller between the two supports as shown.






B. Attach the Ground Floor Support to the Ground Floor Base, as shown below. Make sure you hear a click sound to confirm the support and base are firmly connected. Attach the Main Support to the Ground Floor Base as shown. Tighten it with three screws to secure.





C. Attach the Car Wash to the Ground Floor Base, as shown below. Make sure you hear a click sound to confirm they are firmly connected.




Assemble and attach the first floor components following the steps below:


A. Attach the Repair Lift and the First Floor Support to the First Floor Platform, as shown below. Make sure you hear a click sound to confirm they are firmly connected.



B. Attach the Sliding Track E to the First Floor Platform, as shown below. Tighten it with two screws to secure.



C. Attach the First Floor Platform to the Car Wash Supports, Ground Floor Support and Main Support, as shown below. Make sure you hear a click sound to confirm they are firmly connected.



Assemble and attach the second floor components following the steps below:


A. Attach the Tuning Station Roof to the Tuning Station Support, as shown below, then attach the Tuning Station Support and Tuning Station Plate to the Second Floor Platform as shown. Make sure you hear a click sound to confirm they are firmly connected.







B. Attach the Second Floor Platform to the First Floor Support and Main Support, as shown below. Make sure you hear a click sound to confirm they are firmly connected.




Assemble and attach the sliding track components following the steps below:

A. Insert the Floor Sign Support to the Floor Sign Plate, and then insert it to the Sliding Track A, as shown below. Insert the Track Splitter into Sliding Track B as shown. Make sure you hear a click sound to confirm the Track Splitter and the Track B are firmly connected.









B. Connect the Sliding Track C and Sliding Track D together, and then attach Sliding Track D to the Ground Floor Base, as shown below. Make sure you hear a click sound to confirm they are firmly connected.






C. Attach the Sliding Track B to the Sliding Track C, the First Floor Platform and the Main Support, as shown below. Make sure you hear a click sound to confirm they are firmly connected.



D. Attach the Sliding Tracks A to the Sliding Track B, Main Support and the Second Floor Platform, as shown below. Make sure you hear a click sound to confirm they are firmly connected.



Assemble and attach the remaining components following the steps below:

A. Attach the Spinning Plate to the Main Support, as shown below. Attach the Exit Gate Roof to the Exit Gate Support, as shown below. Make sure you hear a click sound to confirm they are firmly connected.





B. Attach the Exit Gate Support, Exit Gate Handrail, Fuel Stop and Road Sign to the Ground Floor Base, as shown below. Make sure you hear a click sound to confirm they are firmly connected.



Once you've completed the above steps, you are ready to play! You can also connect the play set to other **Toot-Toot Drivers**® play sets (each sold separately).




PRODUCT FEATURES

1. On/Off Switch

To turn the unit **On**, slide the **On/ Off Switch** to the **On** (**(b)**) position.

To turn the unit **Off**, slide the **On/Off Switch** to the **Off** (**()**)
position.




2. Automatic Shut-Off

To preserve battery life, the **Toot-Toot Drivers Stock Car** will automatically power down after approximately 60 seconds without input. The unit can be turned on again by pressing the light up button, pushing the car quickly, opening the bonnet or triggering a **SmartPoint**TM location.

Note: This product is in Try-Me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play. If the unit repeatedly powers down while playing, please install a new set of batteries.

ACTIVITIES Stock Car

 Slide the On/Off Switch to turn the Stock Car On. You will hear a song, fun phrases and sounds. The light will flash with the sounds.



Press the Light Up Button to hear fun sounds, songs, phrases and melodies. The light will flash with the sounds.



Open the Stock Car's Bonnet to hear fun sounds. The light will flash with the sounds.



4. Push the Stock Car to hear fun sounds. If a melody is already playing, push the Stock Car to add fun sounds on the top of the melody. The light will flash with the sounds.




5. For added fun, the Stock Car interacts with the Toot-Toot Drivers® Fix and Fuel Garage. Simply put the Stock Car on one of the play set's six SmartPoint™ locations to hear fun sounds, music, phrases and see the light flash. The Stock Car also interacts with the other Toot-Toot Drivers® play sets (each play set sold separately).



ACTIVITIES

Fix and Fuel Garage

- Place the Stock Car or any SmartPoint[™] vehicle (each sold separately) on any of the play set's six SmartPoint[™] locations to hear fun sounds, music and phrases.
- Place the Stock Car on the Tuning Station, and then press the button to get the Stock Car race ready.









 Place the Stock Car on the Car Wash, and then push the handle to spin the roller to clean the Stock Car.



MELODY LIST

- 1. Home on the Range
- 2. Little Bo Peep
- 3. Jack & Jill
- 4. Old MacDonald
- 5. Polly Put the Kettle On
- 6. Jack Be Nimble

SONG LIST

Song 1

Here we go I'm in first. Here we go now we're tied. Here we go back in first. All out on a speedy fun ride.

Song 2

I like to be at the front of the line. But when I'm with my friends, we all take turns. When's my turn? When's my turn?

Song 3

Toot! Toot! Drivers.
I'm a Toot! Toot! Drivers Stock Car.
I'm build for the faster run. (Toot! Toot!)
Shift the gear, full speed ahead.
Let's Go! Go! and see! (Toot! Toot!)

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries if the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **On**. The unit should now be ready to play with again.
- 5. If the product still does not work, install a brand new set of batteries.

CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk www.vtech.com.au

