

vtech[®]

User's Manual

Colour Notebook



2012 VTech
Printed in China
91-001654-000 ^{UK}

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

**Electronic Learning
Computers**

**Cool, aspirational
and inspiring
computers
for curriculum
related learning**

vtech Baby

**Toys that will
stimulate their
interest in different
textures, sounds
and colours**

I am...

...responding to colours,
sounds and textures

...understanding cause
and effect

...learning to touch,
reach, grasp, sit-up,
crawl and toddle

Pre-School

**Interactive toys to
develop their
imagination and
encourage language
development**

I want...

...to get ready for school
by starting to learn the
alphabet and counting

...my learning to be as
fun, easy and exciting as
can be

...to show my creativity
with drawing and music
so my whole brain
develops

I need...

...challenging activities
that can keep pace with
my growing mind

...intelligent technology
that adapts to my level
of learning

...National Curriculum
based content to
support what I'm
learning at school

Birth-36 months



3-6 years



4-10 years




To learn more about this and other VTech® products, visit www.vtechuk.com

INTRODUCTION

Thank you for purchasing the **VTech® Colour Notebook**

Colour Notebook is a fantastic laptop that features 90 great activities that will challenge and inspire young minds! Explore through the different subjects and facts that cover English, French, maths, science, geography and more. The vivid colour screen brings the games and facts to life with bright pictures and captivating animations, making learning a bold adventure!



INCLUDED IN THIS PACKAGE


- One **VTech® Colour Notebook**
- One Colour Notebook instruction manual
- One real mouse

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

Note: Please keep user's manual as it contains important information.

Unlock the packing lockers:



① Rotate the packing locker 90 degrees anti-clockwise

② Pull out the packing locker

GETTING STARTED

POWER SOURCE


The **Colour Notebook** operates on 3 AA sized batteries (AM-3/LR6) or a **VTech®** 7.5V 400mA or 9V 300mA adaptor (sold separately). The AA sized batteries included in the unit are for demo purposes only and are not long-life batteries.

Please remember to remove all batteries from the battery slot if you are using a power supply adaptor.

BATTERY INSTALLATION

NOTE: For best performance, replace with new, alkaline batteries.

- 1 Make sure the unit is turned OFF.
- 2 Locate the battery cover on the bottom of the unit and open it.
- 3 Insert 3 AA sized batteries as illustrated.
- 4 Close the battery cover.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.







Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

AC-DC ADAPTOR

Use a **VTech**® adaptor or any other standard adaptor that complies with EN61558 DC 7.5V  400mA  or 9V  300mA  centre-positive adaptor.

CONNECTING THE ADAPTOR

- 1 Make sure the unit is OFF.
- 2 Take out the batteries.
- 3 Locate the adaptor jack on the left side of the unit.
- 4 Insert the adaptor plug into the unit's adaptor jack.
- 5 Plug the adaptor into a wall outlet.
- 6 Turn the unit ON.

NOTE: The use of an adaptor will override the batteries. Please remove the batteries, before plugging in the adaptor. When the toy is not going to be in use for an extended period of time, unplug the adaptor.

ADAPTORS NOTICE

- The toy is not intended for use by children under 3 years old.
- Only use the recommended toy transformer with this toy.
- The adaptor is not a toy.
- Never clean a plugged in toy with liquid.
- Never use more than 1 adaptor.
- Do not leave plugged in for extended periods of time.

NOTICE TO PARENTS

Regularly examine the adaptor, checking for damage to the cord, plug, transformer or other parts. Do not use the adaptor if there is any damage to it.

ACTIVATE NORMAL PLAY MODE

Follow the below steps to activate normal play mode.

- 1 Turn the unit on.
- 2 Plug in the real mouse into the mouse jack.
- 3 Move the mouse.

The screen will then display 'Normal Mode' to indicate you can now resume normal play.


CONNECTING THE MOUSE

Use only a mouse that is compatible with **VTech**[®] products.

- 1 Locate the mouse jack on the right side of the unit.
- 2 Plug the mouse into the mouse jack.

USING THE MOUSE

- 1 Move the mouse in the direction you want the cursor to move.
- 2 Click the mouse button to make a selection.



CLEANING THE MOUSE

- 1 Following the arrows, use a screwdriver to open the cover on the bottom of the mouse.
- 2 Take the ball out of the mouse and use a dry cloth to clean the mouse and the ball.
- 3 Place the ball back in the mouse, replace the mouse cover and screw the cover closed.



PRODUCT FEATURES

With **Colour Notebook** you can choose from different categories of play and learning:

- Letters and Sounds
- Language Arts
- Brain Booster
- Maths Exploration
- Cool Tools
- French Trainer
- Science & Nature
- Discover the World

TURNING THE UNIT ON AND OFF

Pressing the **ON/OFF BUTTON** will turn the unit **ON**. Pressing the **ON/OFF BUTTON** again will turn the unit **OFF**.

ACTIVITY SELECTION:

MAIN MENU:

When the unit is turned **ON**, you will see a short opening scene and it will enter the Main Menu. You can choose a category in one of these ways.

- 1) Use the arrow keys to select the category you want. Then press the Enter button to select the category.
- 2) Use the cursor keys to move through the categories. Then press the Enter button to select the category.
- 3) Use the mouse to choose the category you want by clicking on the category icon on the screen.
- 4) Press the corresponding category button to enter the category you want directly.

After chose the category, icons for different activities under this category will be shown. You can choose an activity in one of these ways:

- 1) Use the arrow keys to select the activity you want. Then press the Enter button to select the activity.
- 2) Use the cursor keys to move through the categories, then press the Enter button to select.
- 3) Use the mouse to choose the activity you want by clicking on the activity icon on the screen.

LEVEL SELECTION


Pressing the level button will take you to the level selection screen. Use the arrow keys or mouse to select Level 1 (beginner), or Level 2 (expert).


ANSWER

In most activities, the answer will be provided after a certain number of tries.


KEYBOARD LAYOUT

Your **VTech® Colour Notebook** has a full QWERTY keyboard. You will also find the function keys described below:




KEYBOARD HOT KEY:Letters &
Sounds


Press this key to enter the Letters & Sounds category.

Language
Arts


Press this key to enter the Language Arts category.

Brain
Booster


Press this key to enter the Brain Booster category.

Maths
Exploration


Press this key to enter the Maths Exploration category.

Cool
Tools


Press this key to enter the Cool Tools category.

French
Trainer


Press this key to enter the French Trainer category.

Science &
Nature


Press this key to enter the Science & Nature category.

Discover
the World


Press this key to enter the Discover the World category.

Challenge
Level

Press this key to choose an activity's level of difficulty.

Progress
Report

Press this key to review the highest score in each activity.



Press this key to adjust the volume or contrast. There are 5 levels for volume and 2 levels for contrast. Use the arrow keys to adjust, then press this key again to exit to select contrast.

FUNCTION KEYS:




Press this key to exit the current activity and go back to the previous menu.




Press this key to enter the home menu, there are 90 activity icons and each page contains 9 icons.



Press this key to type capital letters. Press it again to type small letters.



Hold this key for capital letters and release it again for small letters.



Press this key to get some helpful instructions for an activity.



Press this key to see the correct answer to a question in most activities. The player will not receive points if this key is pressed.



Press this key to repeat the current instruction or question.



Press this key to see some fun animations.



When typing, use this key to insert a space between words or numbers.



Press this key to turn the background music on or off.




Press this key to pause the current activity or menu you are in. Press any key to continue.




Press the Enter key after choosing to enter your selection.



Press this key to delete the current character or space to the right of the cursor or above the underscore.



Press this key to erase the character to the left of the cursor.



Press the cursor pad to move the cursor up, down, left or right. Press the cursor pad Enter buttons to make a selection.



Use these keys to cycle through choices in activities or in the Main Menu.

AUTOMATIC POWER OFF

To save power, the Colour Notebook automatically shuts down if it does not receive any input after several minutes. Press the **On/Off** button to turn on the unit again. We recommend that you turn off the unit when you have finished playing. Remove the batteries and unplug the adaptor if your Colour Notebook will not be used for an extended period of time.

LOW BATTERY WARNING

When the batteries are low, a low battery warning icon will be shown at the top right of the screen. When this icon shows, you will not be able to increase the volume above a certain level or adjust the brightness until a new set of batteries is installed.

ACTIVITIES

Your **Colour Notebook** offers a total of 90 activities.

Letters and Sounds	A01	Letter Sound
	A02	Racing Sounds
	A03	Letter Case Beginner
	A04	Letter Case Expert
	A05	Letter Launcher Beginner
	A06	Letter Launcher Expert
	A07	Missing Letter Beginner
	A08	Missing Letter Expert

Language Arts	A09	Word Scramble Beginner
	A10	Word Scramble Expert
	A11	Words Learning
	A12	Word Match Beginner
	A13	Word Match Expert
	A14	Rhyming Words Beginner
	A15	Rhyming Words Expert
	A16	Synonyms Beginner
	A17	Synonyms Expert
	A18	Antonyms Beginner
	A19	Antonyms Expert
	A20	Reading Comprehension Beginner
	A21	Reading Comprehension Expert
	A22	Punctuation Beginner
	A23	Punctuation Expert
Brain Booster	A24	Typing Tutor Beginner
	A25	Typing Tutor Expert
	A26	What Looks Different? Beginner
	A27	What Looks Different? Expert
	A28	Speedy Shapes
	A29	Music Builder Beginner
	A30	Music Builder Expert
A31	Shape Puzzle Beginner	
A32	Shape Puzzle Expert	

Maths Exploration	A33	Geometry Beginner
	A34	Geometry Expert
	A35	Road Rally Even
	A36	Road Rally Odd
	A37	Measure It Beginner
	A38	Measure It Expert
	A39	Maths Symbols Beginner
	A40	Maths Symbols Expert
	A41	Addition
	A42	Subtraction
	A43	Add It Up Beginner
	A44	Add It Up Expert
	A45	Sudoku Beginner
	A46	Sudoku Expert
	A47	Skip Counting Beginner
	A48	Skip Counting Expert
Cool Tools	A49	Calculator
	A50	Personal Profile
	A51	My Diary
	A52	Progress Report
French Trainer	A53	French Lesson
	A54	French Letters and Numbers
	A55	French Letter Quiz
	A56	French Number Quiz
	A57	French Number Hunt
	A58	French Training
	A59	French Spelling Beginner
	A60	French Spelling Expert
	A61	French Quiz Beginner
	A62	French Quiz Expert

Science & Nature	A63	Animal World
	A64	Human Body
	A65	Great Inventions
	A66	Science Starter
	A67	Animal Quiz Beginner
	A68	Animal Quiz Expert
	A69	Human Body Quiz Beginner
	A70	Human Body Quiz Expert
	A71	Who Invented What? Beginner
	A72	Who Invented What? Expert
	A73	Science Quiz Beginner
	A74	Science Quiz Expert
	A75	Amazing Animals Beginner
	A76	Amazing Animals Expert
	A77	Animal Family Beginner
	A78	Animal Family Expert
Discover the World	A79	World Wonders
	A80	Space Exploration
	A81	Ocean Wonders
	A82	Secrets of the Earth
	A83	World Wonders Quiz Beginner
	A84	World Wonders Quiz Expert
	A85	Space & Planet Quiz Beginner
	A86	Space & Planet Quiz Expert
	A87	Ocean Quiz Beginner
	A88	Ocean Quiz Expert
	A89	Earth Challenge Beginner
	A90	Earth Challenge Expert

Letters & Sounds

A01: Letter Sound

Press a letter to hear it said aloud, its phonic sound and a word beginning with that letter. A picture of the word will also be shown.

A02: Racing Sounds

Let's get racing! Listen carefully to the phonic sound said aloud and find the matching letter.

A03: Letter Case Beginner

It's time to match letters! An upper case letter will be displayed at the top of the screen, press the left or right arrow to select the matching lower case letter.

A04: Letter Case Expert

It's time to match letters! A lower case letter will be displayed at the top of the screen, press the left or right arrow to select the matching upper case letter.

A05: Letter Launcher Beginner

Fill in the missing letter to complete the word! The crab is holding a letter bubble, move it left or right to get below the correct word and press enter to launch it. Watch out for the fish!

A06: Letter Launcher Expert

Fill in the missing letter to complete the word! The crab is holding a letter bubble, move it left or right to get below the correct word and press enter to launch it. Watch out for the fish!

A07: Missing Letter Beginner

It's boating time! Move the boat left and right to collect the letter that's missing from the word.

A08: Missing Letter Expert

It's boating time! Move the boat left and right to collect the letter that's missing from the word.

Language Arts

A09 and A10: Word Scramble Beginner and Expert

The birds will show you a word, then they will rearrange themselves, scrambling the word. Move the birds around to make up the correct word.

A11: Words Learning

Here you can learn new words! Choose a word to see its definition and a matching picture.

A12: Word Match Beginner

It's test time! A picture will be shown on the screen, select the word that matches it.

A13: Word Match Expert

It's test time! A picture will be shown on the screen, select the word that matches it.

A14: Rhyming Words Beginner

Rhyme time! A word will be displayed at the top of the screen, select the word that rhymes with it.

A15: Rhyming Words Expert

Rhyme time! A word will be displayed at the top of the screen, select the word that rhymes with it.

A16: Synonyms Beginner

Choose a word that has the same meaning as the word shown at the top of the screen. Move the crab left or right to get below the correct word and press enter to launch the bubble. Watch out for the fish!

A17: Synonyms Expert

Choose a word that has the same meaning as the word shown at the top of the screen. Move the crab left or right to get below the correct word and press enter to launch the bubble. Watch out for the fish!

A18: Antonyms Beginner

Choose a word that has the opposite meaning of the word shown at the top of the screen. Move the crab left or right to get below the correct word and press enter to launch the bubble. Watch out for the fish!

A19: Antonyms Expert

Choose a word that has the opposite meaning of the word shown at the top of the screen. Move the crab left or right to get below the correct word and press enter to launch the bubble. Watch out for the fish!

A20: Reading Comprehension Beginner

Read through the stories and answer the related questions. There are lots of stories to read though!

A21: Reading Comprehension Expert

Read through the stories and answer the related questions. There are lots of stories to read though!

A22: Punctuation Beginner

Let's check your punctuation skills! Choose the punctuation mark that is correct for the sentence displayed.

A23: Punctuation Expert

Let's check your punctuation skills! Choose the punctuation mark that is correct for the sentence displayed.

A24: Typing Tutor Beginner

Are you good at typing? Quickly type the letters when they appear on the screen before they disappear.

A25: Typing Tutor Expert

Are you good at typing? Quickly type the words when they appear on the screen before they disappear.

Brain Booster**A26: What Looks Different? Beginner**

Can you spot the differences between the two pictures? Use the mouse or cursor pad to play. Hurry before time runs out!

A27: What Looks Different? Expert

Can you spot the differences between the two pictures? Use the mouse or cursor pad to play. Hurry before time runs out!

A28: Speedy Shapes

Let's test your counting skills! Count the vehicles that are passing by with the shape shown on the sign. Press the Enter button to activate the counter.

A29: Music Builder Beginner

Add the music note values together to equal the number shown on the right of the screen. Press the arrow keys to play. Hint: you can press the pause button if you're having trouble!

A30: Music Builder Expert

Add the music note values together to equal the number shown on the right of the screen. Press the arrow keys to play. Hint: you can press the pause button if you're having trouble!

A31: Shape Puzzle Beginner

This is a logic game! Fill the empty spaces with the different shapes. Only one of each shape can be placed in each row, column and grid section.

A32: Shape Puzzle Expert

This is a logic game! Fill the empty spaces with the different shapes. Only one of each shape can be placed in each row, column and grid section.

Maths Exploration**A33: Geometry Beginner**

How well do you know your shapes? A shape will be shown and a question related to it will be asked on the screen. There are three different themes to play through!

A34: Geometry Expert

How well do you know your shapes? A shape will be shown and a question related to it will be asked on the screen. There are three different themes to play through!

A35: Road Rally Even

Let's test your counting skills! Count all of the vehicles passing by that have an even number displayed. Press the Enter button to activate the counter.

A36: Road Rally Odd

Let's test your counting skills! Count all of the vehicles passing by that have an odd number displayed. Press the Enter button to activate the counter.

A37: Measure It Beginner

How well do you know your units of measure? Look carefully and count all of the vehicles that display the unit of measure that's displayed on the sign. Press the enter button to play!

A38: Measure It Expert

How well do you know your units of measure? Look carefully and count all of the vehicles that display the unit of measure that's displayed on the sign. Press the enter button to play!

A39: Maths Symbols Beginner

Let's test your maths skills! A sum will be shown at the top of the screen. Work out the total of the first two numbers to see if they are less than or more than the number shown on the right.

A40: Maths Symbols Expert

Let's test your maths skills! A sum will be shown at the top of the screen. Work out the total of the first two numbers to see if they are less than or more than the number shown on the right.

A41: Addition

The birds will show you a sum, then they will rearrange themselves, scrambling it. Move the birds back in to place to recreate the sum.

A42: Subtraction

The birds will show you a sum, then they will rearrange themselves, scrambling it. Move the birds back in to place to recreate the sum.

A43: Add It Up Beginner

Add the note blocks together to equal the number shown on the right of the screen. Press the arrow keys to play. Hint: you can press the pause button if you're having trouble!

A44: Add It Up Expert

Add the note blocks together to equal the number shown on the right of the screen. Press the arrow keys to play. Hint: you can press the pause button if you're having trouble!

A45: Sudoku Beginner

This is a logic game! Fill the empty spaces with a number. Only one of each number can be placed in each row, column and grid section.

A46: Sudoku Expert

This is a logic game! Fill the empty spaces with a number. Only one of each number can be placed in each row, column and grid section.

A47: Skip Counting Beginner

A sequence of numbers will be displayed at the top of the screen, but with one missing. Can you work out the missing number?

A48: Skip Counting Expert

A sequence of numbers will be displayed at the top of the screen, but with one missing. Can you work out the missing number?

Cool Tools**A49: Calculator**

You can use this calculator for addition, subtraction, multiplication and division. To use, click on the screen or use the calculator keys on the keyboard.

A50: Personal Profile

Here you can store details about yourself: store your name, birthday, phone number and home address.

A51: My Diary

You can keep your own diary here. You can create up to 30 separate diaries, each with a total of 500 characters.

A52: Progress Report

Here you can see how well you are doing in all of the activities. You will see a bar chart to all relevant activities. Each page shows a maximum of 3 activities.

French Trainer**A53: French Lesson**

It's time to learn French words! In this activity, you will see a list of words in English with their French equivalent and an accompanying picture. Click the word to hear it said aloud. Both French and English words can be heard.

A54: French Letters and Numbers

Here you can learn French letters and numbers! Click on a swimmer or type a letter or number to hear it spoken in French.

A55: French Letter Quiz

It's time for a swimming competition! Listen carefully, a French letter will be spoken. Choose the correct answer from the options shown. Use the arrow keys to choose and press the enter button to confirm or press letter keys to answer directly.

A56: French Number Quiz

It's time for a swimming competition! Listen carefully, a French number will be spoken. Choose the correct answer from the options shown. Use the arrow keys to choose and press the enter button to confirm or press letter keys to answer directly.

A57: French Number Hunt

Do you know how to spell numbers in French? A French number will be spoken and the word written at the top of the screen. Use the arrow keys to choose the correct number that matches it.

A58: French Training

Let's test your typing skills! Type the French words correctly before they reach the top of the screen. You will hear the letters in spoken in French as you're typing, then the word spoken once it is complete.

A59: French Spelling Beginner

It's fishing time! Look carefully at the spelling of the word, then use the arrow keys to move the boat to catch the fish with the missing letter.

A60: French Spelling Expert

It's fishing time! Look carefully at the spelling of the word, then use the arrow keys to move the boat to catch the fish with the missing letter.

A61: French Quiz Beginner

It's time to test your French word knowledge! Can you find the French word that matches the English word shown?

A62: French Quiz Expert

It's time to test your French word knowledge! Can you find the French word that matches the English word shown?

Science & Nature**A63: Animal World**

Here you can discover lots of facts about the animal kingdom. Use the arrow keys to choose between the categories and to look at the different facts.

A64: Human Body

In this activity, you can learn lots of facts about the human body. Use the arrow keys to choose between the categories and to look at the different facts.

A65: Great Inventions

Let's learn facts about some great inventions! Use the arrow keys to choose between the categories and to look at the different facts.

A66: Science Starter

This activity will show you facts about different areas of science. Use the arrow keys to choose between the categories and to look at the different facts.

A67: Animal Quiz Beginner

Let's test your knowledge of animals! There are three different themes for you to play through. Be quick, before time runs out!

A68: Animal Quiz Expert

Let's test your knowledge of animals! There are three different themes for you to play through. Be quick, before time runs out!

A69: Human Body Quiz Beginner

Let's see how much you know about the human body! There are three different themes for you to play through. Be quick, before time runs out!

A70: Human Body Quiz Expert

Let's see how much you know about the human body! There are three different themes for you to play through. Be quick, before time runs out!

A71: Who Invented What? Beginner

Test your knowledge of great inventions here! There are three different themes for you to play through. Be quick, before time runs out!

A72: Who Invented What? Expert

Test your knowledge of great inventions here! There are three different themes for you to play through. Be quick, before time runs out!

A73: Science Quiz Beginner

It's time to see how much you know about science! There are three different themes for you to play through. Be quick, before time runs out!

A74: Science Quiz Expert

It's time to see how much you know about science! There are three different themes for you to play through. Be quick, before time runs out!

A75: Amazing Animals Beginner

Test your knowledge of animals here! You will be asked questions that are specifically related to a particular animal, select the answer you think is correct.

A76: Amazing Animals Expert

Test your knowledge of animals here! You will be asked questions that are specifically related to a particular animal, select the answer you think is correct.

A77: Animal Family Beginner

How much do you know about animals? Identify which animal is related to the question asked. Quickly, before time runs out!

A78: Animal Family Expert

How much do you know about animals? Identify which animal is related to the question asked. Quickly, before time runs out!

Discover the World**A79: World Wonders**

Our world is a fascinating place, with many things to discover. Here you can learn facts about thirteen famous places from different parts of our planet. Use the arrow keys to choose between the categories and to look at the different facts.

A80: Space Exploration

Would you like to know more about space? Let's learn some facts about things beyond our planet! Use the arrow keys to choose between the categories and to look at the different facts.

A81: Ocean Wonders

The oceans of the Earth are deep and mysterious. Let's look at some facts to find out something about them! Use the arrow keys to choose between the categories and to look at the different facts.

A82: Secrets of the Earth

There are many things to learn about the Earth! Let's have a look at some of them in this activity. Use the arrow keys to choose between the categories and to look at the different facts.

A83: World Wonders Quiz Beginner

Let's test your knowledge of the wonders of the world! There are three different themes for you to play through. Answer quickly, before time runs out!

A84: World Wonders Quiz Expert

Let's test your knowledge of the wonders of the world! There are three different themes for you to play through. Answer quickly, before time runs out!

A85: Space & Planet Quiz Beginner

How much do you know about space? There are three different themes for you to play through. Answer quickly, before time runs out!

A86: Space & Planet Quiz Expert

How much do you know about space? There are three different themes for you to play through. Answer quickly, before time runs out!

A87: Ocean Quiz Beginner

Let's see how much you know about the Earth's oceans! There are three different themes for you to play through. Answer quickly, before time runs out!

A88: Ocean Quiz Expert

Let's see how much you know about the Earth's oceans! There are three different themes for you to play through. Answer quickly, before time runs out!

A89: Earth Challenge Beginner

Are you ready to test your knowledge on facts about the Earth? There are three different themes for you to play through. Answer quickly, before time runs out!

A90: Earth Challenge Expert

Are you ready to test your knowledge on facts about the Earth? There are three different themes for you to play through. Answer quickly, before time runs out!

CARE & MAINTENANCE

- 1 Keep your **Colour Notebook** clean by wiping it with a slightly damp cloth. Never use solvents or abrasives.
- 2 Keep it out of direct sunlight and away from direct sources of heat.
- 3 Remove the batteries when not using it for an extended period of time.
- 4 Avoid dropping it. **NEVER** try to dismantle it.
- 5 Always keep the **Colour Notebook** away from water.

WARNING:

- A very small percentage of the public, due to an existing condition, may experience epileptic seizures or momentary loss of consciousness when viewing certain types of flashing colours or patterns.
- While the **Colour Notebook** does not contribute to any additional risks, we do recommend that parents supervise their children while they play games. If your child experiences dizziness, altered vision, disorientation, or convulsions, discontinue use immediately and consult your doctor.
- Please note that focusing on a screen at close range and handling a keyboard for a prolonged period of time may cause fatigue or discomfort. We recommend that children take a 15 minute break for every hour of play.

TROUBLESHOOTING

1. If your Colour Notebook stops working or does not turn on:

- Check your batteries. Make sure the batteries are fresh and properly installed.
- If you are still having problems, visit our website at www.vtechuk.com for troubleshooting tips.

2. If when pressing the ON/OFF button, nothing happens:


- Make sure your unit is plugged in.
- If you are using batteries, check to see that they are aligned correctly.

3. If you turn the unit on, but cannot see anything on the screen:

- Adjust the contrast switch to change the darkness of the screen.

4. If you can't hear any sound:

- Adjust the volume switch to change the sound level of the speaker.



TECHNICAL SUPPORT

If you have a problem that cannot be solved by using this manual, we encourage you to visit us online or contact our Consumer Services Department with any problems and/or suggestions that you might have. A support representative will be happy to assist you.

Before requesting support, please be ready to provide or include the information below:

- The name of your product or model number (the model number is typically located on the back or bottom of your product).
- The actual problem you are experiencing.
- The actions you took right before the problem started.

Internet: www.vtechuk.com

Phone: 01235 546810 (from UK), or +44 1235 546810 (outside UK)

OTHER INFO

DISCLAIMER AND LIMITATION OF LIABILITY

VTech[®] Electronics Europe PLC and its suppliers assume no responsibility for any damage or loss resulting from the use of this notebook. **VTech**[®] Electronics Europe PLC and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this hardware and software. **VTech**[®] Electronics Europe PLC and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead batteries or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

Company: **VTech**[®] Electronics Europe PLC

Address: Napier Court, Abingdon Science Park, Abingdon, Oxon, OX14 3YT

Phone: (01235) 546810 (from UK), +44 1235 546810 (outside UK)

IMPORTANT NOTE

Creating and developing **VTech**[®] Electronic Learning products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK), or +44 1235 546810 (outside UK) with any problems and/or suggestions that you might have. A service representative will be happy to help you.

COPYRIGHT NOTICES:

Copyright © 2012 **VTech**[®] VTech Electronics Europe PLC. All Rights Reserved. **VTech**[®] and the **VTech**[®] logo are registered trademarks of **VTech**[®] VTech Electronics Europe PLC. All other trademarks are property of their respective owners.



PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

